



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 601-151**

US Patent# US 7,263,961B2

Application : 2007-2008 FORD Freestyle V6

**Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 15mm x 12" Hose/ 1 x 3"- 3" Coupler
2 x 2.5"-3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp**

- 1 Remove bolts securing OEM air intake, and tube loosen clamps on OEM rubber intake pipe.
- 2 Remove 15mm PCV hose from OEM intake and engine.
- 3 Unplug mass air sensor, and Remove OEM airbox lid with mass air sensor attached
- 4 Unbolt mass air sensor from top of OEM airbox, put aside.
- 5 Remove the OEM rubber intake tube.
- 6 Remove rest of OEM airbox
- 7 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 8 Install the WR intake tube into 3" side of coupler and clamp down
- 9 Measure the OEM PVC hose, replace with supplied 15mm hose, install from PCV port to intake pipe.
- 10 Replace OEM 15mm line to intake pipe, or use (mm hose supplied and replace complete line
- 11 Install 2.5" 3" coupler onto Secret Weapon air filter, secure 3" side with supplied clamp.
- 12 Install filter assembly onto the end of Weapon*R pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

