



Part # 's **Secret Weapon Intake : 601-153**

Application : **2008 Ford Escape V6**

Recommended Air Filter Cleaning Intervals: 3000 Miles.

US Patent# US 7,263,961B2

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 1 x 10mm x 12" hose

1 x 3"-3" Coupler / 1 x 2.5"-3" coupler/ 1 x Intake System Bracket kit / 1 x 3" clamp

- 1 Remove the emissions box from OEM tube, Disconnect the plastic PCV 15mm hardline from OEM intake pipe.
- 2 Loosen the OEM airbox and rubber intake tube, disconnect the MAF sensor harness from OEM airbox
- 3 Carefully remove the MAF sensor from the OEM airbox, remove the rubber intake tube and OEM airbox
- 4 Place the 2.5"- 3" coupler onto the throttle body and secure with the OEM clamp.
- 5 Place Weapon*R Intake Tube into the 3" end of the coupler and secure with clamp.
- 7 Install a small 4" piece of the 10mm line onto the WR 10mm port on tube.
- 8 Reinstall the OEM PCV line into the 4" 10mm stub
- 9 Install the MAF sensor onto the Weapon-R intake pipe, secure with OEM screws, reconnect harness.
- 10 Insert the Weapon*R filter into the intake pipe, secure with clamp.

Note: Secret Weapon Filter Option

- 11 Install 3"- 3" coupler onto Secret Weapon air filter, secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.

- 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

NOTE: Only some early models used a MAF sensor. Disregard MAF info if not applicable to your vehicle.

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

