



ARB # D-489

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 901-138 / Dragon Intake : 801-138**

Application : **94-97 Passport / 90-97 Rodeo 2.6L V6 EFI**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 1 x 10mm x 24" Hose
1 x 2.5"- 3" Coupler / 1 x 3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp

Note: Additional Parts needed when you have a Dragon Filter.

1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove the coolant transfer / PCV hardline from OEM intake and engine.
 - 3 Remove and set aside OEM MAF sensor.
 - 4 Mark the coolant transfer hose origins, install the 10mm hose supplied in kit to those 2 locations.
 - 5 Disconnect the OEM AIT sensor harness , remove from OEM rubber intake pipe.
 - 6 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 7 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
 - 8 Insert the intake pipe into 2.5"-3" coupler on throttlebody, secure with supplied clamp.
 - 9 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
 - 10 Cut a 1.5" portion of the 10mm hose and place on the larger port on the Weapon*R intake pipe.
 - 11 Insert the OEM AIT sensor into the 1.5" x 10mm hose on Weapon*R intake pipe, reconnect AIT harness.
 - 12 Install the hoses from their point of origin and onto the Weapon *R intake pipe.
 - 13 Install 3" coupler onto end of intake pipe. Insert OEM MAF sensor into 3" coupler. Secure with supplied clamps.
 - 14 Install the Weapon*R Hyper filter onto the MAF sensor
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 15 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
 - 16 Install filter assembly onto the MAF sensor, secure with clamp.
 - 17 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 18 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 19 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 20 Secure with washer and nut included in bracket kit.
 - 21 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 22 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 23 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

