



Recommended [Air Filter](#) Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 904-122 / Dragon Intake : 804-122**

Application : **2001-2004 NISSAN PATHFINDER 3.5L V6**

**(2002-2004 PATHFINDER #D-489-2 ONLY)**

Parts List : 1 x Intake pipe. / 1 x Air Filter / 3 x 3" coupler / 1 x 4mm x 12" hose / 1 x 15mm x 12" hose  
1 x Intake Bracket kit / 6 x 3" Clamp / 1 x 9mm 12mm hose, 1 x AFM-NS2 Adapter plate.

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the 15mm PCV hose from OEM intake.
- 3 Remove the 4mm hose from the air OEM intake pipe.
- 4 Unplug and remove the MAF sensor from the air intake system.
- 5 Remove the 9mm line from the OEM intake tube
- 6 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 7 Install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 8 Insert Weapon\*R intake pipe into the coupler, secure with clamp.
- 9 Install the supplied 15mm hose onto the intake pipe and to the PCV valve on valvecover.
- 10 Install the supplied 4mm hose onto the intake pipe and to the air resonator box.
- 11 Install the supplied 9mm hose to the intake pipe and the OEM location.
- 12 Install the 3" coupler onto end of intake pipe, secure with clamp.
- 13 Insert MAF into the 3" coupler, secure with clamp, connect MAF harness.
- 14 Line up the holes on MAF to the AFM-NS2 adapter plate, secure with nuts and bolts in kit.
- 15 Tie AIT sensor to any wire harness on fender well, to measure ambient air temperatures.
- 16 Install the Weapon\*R Hyper filter onto AFM adapter plate..
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 17 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 18 Install filter assembly onto the AFM adapter plate, secure with OEM clamp.
- 19 Install U-shaped part of intake system bracket under the clamp on air filter.
- 20 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 21 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 22 Secure with washer and nut included in bracket kit.
- 23 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 24 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 25 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

