



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 906-111 / Dragon Intake : 806-111**

Application : **1998 Subaru Forester 2.5I / 1998 Impreza 2.5I / 1995-1998 Impreza 2.2I /
1995-1998 Legacy 2.5L / 1990-1998 Legacy 2.2L
1998 FORESTER/ IMPREZA/ LEGACY 2.5L #D-489-2 ONLY)**

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 2 x 10mm x 24" Hose / 1x 10mm T-fitting / 1 x 2.75" coupler
1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x AFM subaru Adapter plate/ 1 X 15MM
Note: Additional Parts needed when you have a Dragon Filter, 2 x 3"-3" Coupler / 2 x 3" Clamp**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the PCV hoses from OEM intake and engine. Mark locations on engine.
- 3 Unplug and remove the MAF sensor from the air intake system.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 2.75" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon*R intake pipe into the 2.75" coupler, secure with clamp.
- 7 Measure from valve cover PCV ports to Tee fitting, and from Tee fitting to intake pipe. Replace with supplied 10mm hoses.
- 8 Measure from crankcase PCV port to 10mm port on intake pipe. Replace with supplied 10mm hose.
- 9 Measure from Idle Air Control valve to 15mm intake pipe port. Replace with supplied 15mm hose.
- 10 Stretch the 2.5-3" coupler onto end of intake pipe, secure with clamp.
- 11 Insert MAF into the 2.5-3" coupler, secure with clamp, connect MAF harness.
- 12 Line up the holes on MAF to the AFM subaru adapter plate, secure with nuts and bolts in kit.
Install the Weapon*R Hyper filter onto AFM adapter plate.
- 13 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 14 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 15 Install filter assembly onto the AFM adapter plate, secure with OEM clamp.
- 16 Install U-shaped part of intake system bracket under the clamp on air filter.
- 17 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 19 Secure with washer and nut included in bracket kit.
- 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 22 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

