



TALKING BACK-UP ALARM

ALARMA PARLANTE

MOUNTING

1. Find a location for the alarm under the rear of vehicle in an area which will stay dry and safe from exhaust system.
2. Using the alarm's mounting bracket as template, drill (1) 5/16 inch hole, secure with screw, washer and nut.

WIRING

1. RED WIRE splice the alarm's red wire to the vehicles back-up bulb's power wire. The back-up bulb and its wire are located behind the white lens.
2. BLACK WIRE connect alarm's black wire to a good ground. Secure under a body bolt, make sure that the surface around bolt is clean of rust and paint to make a good electrical connection.
3. Secure all wires and tape electrical connections.

MONTAJE

1. Busque un lugar para la alarma debajo de la parte trasera del vehículo en una área que permanezca seca y a salvo del sistema de escape.
2. Usando el soporte de montaje de la alarma como muestra, taladre (1) un agujero de 8 mm (5/26) asegúrelo con un tornillo, arandela y tuerca.

CABLEADO

1. CABLE ROJO - junte el alambre rojo de la alarma a la bombilla retrocedente de la alarma del alambre de potencia del vehículo. La bombilla retrocedente y su alambre están localizados detrás del lente blanco.
2. CABLE NEGRO conecte el alambre negro en un sitio seguro. Asegúrelo bajo un perno del cuerpo del perno, asegurándose que la superficie esté libre de óxido y pintura para hacer una buena conexión eléctrica.
3. Asegure todo el cableado y pegue las conexiones eléctricas con cinta aislante