

How to Switch to Amber Daytime Running Light (DRL) for AlphaRex 14-24 Toyota 4Runner Headlights

Table of Contents

- AMBER SWITCH PLUG LOCATION
- CONNECT THE AMBER SWITCH PLUGS
- COMPLETE THE SWITCH TO AMBER DRL & PARKING LIGHTS

Disclaimer: This installation article is a tutorial guide. By reading this article, you agree it is for reference only and AlphaRex USA and its distributors make no guarantee on the finished results. Under no circumstances whatsoever shall AlphaRex USA nor its distributors be liable for any damage, misuse or personal injuries. If you do not fully understand the installation procedure, it is highly recommended that you seek help from professional mechanics to do the installation.

This instruction guide is applicable to the following ALPHAREX headlight products:

- 14-23 Toyota 4Runner MKII NOVA-Series LED Projector Headlights (Black) / SKU:880808
- 14-23 Toyota 4Runner MKII NOVA-Series LED ProjectorHeadlights (Chrome) / SKU:880809
- 14-23 Toyota 4Runner MKII NOVA-Series LED ProjectorHeadlights (Alpha Black) / SKU:880810
- 14-23 Toyota 4Runner MKII LUXX-Series LED ProjectorHeadlights (Black) / SKU:880811
- 14-23 Toyota 4Runner MKII LUXX-Series LED Projector Headlights (Chrome) / SKU:880812
- 14-23 Toyota 4Runner MKII LUXX-Series LED Projector Headlights (Alpha Black) / SKU:880813


In the product list, the LUXX-Series and the NOVA-Series headlights designed for the 2014-23 Toyota 4Runner offer an optional switch plug, allowing you to customize the color of the Daytime Running Lights (DRL) and Parking lights to Amber (Yellow). By default, these lights come in White from the factory.

Customers have the flexibility to choose Amber (Yellow color) based on their preference. PLEASE NOTE: Once you have plugged in and switched to Amber, the color of the Daytime Running Lights (DRL) and Parking lights will remain in Amber (Yellow color).




AMBER SWITCH PLUG LOCATION

Remove the light dust cover from each ALPHAREX headlight.



Inside the headlight, locate plug connectors designed for switching to Amber (Yellow color) DRL & Parking lights.



CONNECT THE AMBER SWITCH PLUGS

Directly connect the amber DRL plugs to each of the headlights.
DO NOT USE DIELECTRIC GREASE!



COMPLETE THE SWITCH TO AMBER DRL & PARKING LIGHTS

After plugging in the connection, reinstall the headlights onto the vehicle. Congratulations! You have successfully switched to Amber (Yellow color) Daytime Running Lights (DRL) and Parking lights

