

How to Switch to Amber Daytime Running Light (DRL) for AlphaRex 19-24 Toyota Rav4 Headlights

Table of Contents

- AMBER SWITCH PLUG LOCATION
- CONNECT THE AMBER SWITCH PLUGS
- COMPLETE THE SWITCH TO AMBER DRL & PARKING LIGHTS

Disclaimer: This installation article is a tutorial guide. By reading this article, you agree it is for reference only and AlphaRex USA and its distributors make no guarantee on the finished results. Under no circumstances whatsoever shall AlphaRex USA nor its distributors be liable for any damage, misuse or personal injuries. If you do not fully understand the installation procedure, it is highly recommended that you seek help from professional mechanics to do the installation.

From **The product models list**, the NOVA-Series headlights for 2019-23 Toyota RAV4 will come with optional switch plugs for Amber (Yellow color) DRL & Parking lights.

By default the DRL & Parking lights color are White from factory.


CUSTOMERS CAN CHOOSE TO SWITCH TO AMBER (YELLOW COLOR) BASED ON THEIR PREFERENCE.

PLEASE NOTE: Once you have plugged in and switch to Amber, the DRL & Parking lights color will remain Amber (Yellow color).




AMBER SWITCH PLUG LOCATION

To access the dust cover on the rear of each ALPHAREX headlight, simply twist it open.



Inside of the headlight, you will find the plug connectors for switching into Amber (Yellow color) DRL & Parking lights.



CONNECT THE AMBER SWITCH PLUGS

Connect the pairs of amber DRL plugs directly into each of the headlights.
DO NOT USE DIELECTRIC GREASE!



COMPLETE THE SWITCH TO AMBER DRL & PARKING LIGHTS

After plugging in the connections, please install the headlights back on to the vehicle.
Congratulations! You have switched to Amber (Yellow color) DRL & Parking lights.

