





Description: Universal 4 Channel Remote Control Module

Application: Pairing second remote control

Universal 4 Channel Remote Control Module

Connect the 4 Channel Remote Control Module to 12 volts. Once the Remote Control Module is energized press the program button on the back of the module. Then press the number 1 button on the remote control. Pairing should take less than 10 second to activate. Cycle through 1-4 to ensure that all channels are response via the remote control. You could pair up to 3 remote controls.



With our earlier models, you will have to open the module by unscrewing the four Phillips screws located by the power connections. With the module energized press the program button located on the upper center of the circuit board and program remote control. Once confirmed that the remote control is working with the module, disconnect fuse and tighten the four Phillips screws securing the case to the module housing.