



For easy and trouble-free separation of quick disconnect and spring lock couplers found on most late model domestic and import vehicles.

Sizes included in set: 1/4", 5/16", 3/8", 1/2", 5/8", 3/4" and 7/8"

## For use on:

- Fuel lines
- Fuel filters
- Fuel pressure regulators
- Fuel return lines
- A/C Fittings
- Oil cooler lines
- Transmission oil cooler lines
- Radiator cooler lines
- Vehicle specific applications

## **INSTRUCTIONS**

Select the appropriate <u>disconnect tool</u>. The engagment tip should be approximately the same diameter as the spring or the open side of fuel line fitting. Twist tool to open and slip over fuel line with engagement tip facing the open or spring side of the fuel line fitting. Insert engagement tip into the fuel line fitting. A "click" may be heard as fuel line releases. Seperate the fuel line pieces. Press the fuel line fittings together to connect.



Ford CF fuel lines w/hair pin connectors: universal for radiator to transmission oil cooler lines: '87 & newer Olds Toronado; Buick Riviera, Regatta; Cadillac Eldorado, Seville & Concourse: '89 & newer GM 1/2-ton, 3/4-Ton and 1-Ton Pickups



Ford oil cooler line disconnect tool 1990 & newer Ford vehicles with AXOD, AOD or ATX automatic transmissions



1990 & newer Ford Rangers & Explorers with 4.0L cylinder engines



"Scissors" Type Fuel line disconnect tool (5/16" & 3/8")



Black anodized aluminum separates fittings on fuel lines, fuel filters & fuel tank return lines Size: 1/4"



Red anodized aluminum separates fittings on fuel lines, fuel filters & fuel tank return lines Size: 5/16"



Yellow anodized aluminum separates fittings on fuel lines, fuel filters & fuel tank return lines Size: 3/8"



Blue & Purple Oil cooler line disconnect tool anodized aluminum separates automatic transmissionoil cooler lines on Ford Taurus and Escort with AXOD and ATX transmission



6pc Fuel line disconnect set- size: 3/8", 5/16", 1/2", 5/8", 3/4", 7/8"





ITEM#	ORDERING PART#	PART DESCRIPTION
1	PRT3399-01	OIL COOLER LINE REMOVER (PURPLE)
2	PRT3399-02	DISCONNECT TOOL 3/8" (YELLOW)
3	PRT3399-03	DISCONNECT TOOL 5/16" (RED)
4	PRT3399-04	OIL COOLER LINE DISCONNECT TOOL (BLUE)
5	PRT3399-05	DISCONNECT TOOL 1/4" (BLACK)
6	PRT3399-06	SCISSORS TYPE DISCONNECT TOOL (3/8" & 5/16")
7	PRT3399-07	FORD OIL COOLER LINE DISCONNECT TOOL
8	PRT3399-08	FORD DISCONNECT TOOL
9	PRT3399-09	CF LINE DISCONNECT TOOL
10	PRT3399-10	RUBBER BAND AND GROMMET SET (4 PCS)
11	PRT3399-11	7/8" FUEL LINE DISCONNECT (WHITE PLASTIC)
12	PRT3399-12	3/4" FUEL LINE DISCONNECT (BLACK PLASTIC)
13	PRT3399-13	5/8" FUEL LINE DISCONNECT (BLUE PLASTIC)
14	PRT3399-14	1/2" FUEL LINE DISCONNECT (RED PLASTIC)
15	PRT3399-15	3/8" FUEL LINE DISCONNECT (LIGHT BLUE PLASTIC)
16	PRT3399-16	5/16" FUEL LINE DISCONNECT (GREY PLASTIC)