

## AC-32 USB TO RS232 ADAPTER CABLE



For use with computers that do not have a serial port connection

Please follow the instructions on the website to download the device driver. The driver type you want to choose is the Virtual COM Port (VCP).



Learn more about gauges and dashboards we have.