

Part # 2782 Measuring Cup

Instructions



Helps eliminate the chance of system failure due to over- or under-filling the A/C system.

2 cup/500 ml capacity.

Made of non-breakable plastic.

Instructions:

- 1. Place the cup on a flat surface when measuring liquids to ensure an accurate measurement.
- 2. Fill cup to the appropriate measuring line.
- 3. View at eye level to ensure correct volume has been reached.

ALWAYS WEAR PROTECTIVE EYEWEAR AND RUBBER GLOVES WHEN SERVICING ANY A/C SYSTEM

FJC Air Conditioning Products—Tools, Equipment & Refrigerant