

SKU	Transmission Model	Transmission Control Type	Note
4301622	FS-4205A	Input Shaft	
239803	FS-4005A	Input Shaft	
239809	FS-4005C	Input Shaft	Use 238104 Front Bearing Cover.
239808	FS-4005C	Input Shaft	Use 239821 or 4300882 Front Bearing Cover.
4301526	FS-4205A	Input Shaft	
4301628-B	FS-4205C	Input Shaft	Use 4300882 Front Bearing Cover.
4301626	FS-4205C	Input Shaft	Use 4300882 Front Bearing Cover.
235354	FS-5005A	Input Shaft	Use 235358 or 4300354 Front Bearing Cover.
235351	FS-5005A	Input Shaft	Use 4300882 Front Bearing Cover.
235355	FS-5005B	Input Shaft	
3316314	FS-5106A	Input Shaft	Use 3316313 Front Bearing Cover.
4301879	FS-5205A	Input Shaft	Use 4300355 Front Bearing Cover.
4301408	FS-5306A	Input Shaft	
21896	FS-5106A	Input Shaft	Use 21893 Front Bearing Cover.
23144	FS-4005A	Input Shaft	
21988	FS-5106A	Input Shaft	Use 21982 Front Bearing Cover.
4304539-B	F-5405B-DM3	Input Shaft	Pilot 30 mm.
4304539	F-5405B-DM3	Input Shaft	Pilot 30 mm.
4304540	FO-6406A-ASX	Input Shaft	
4301403-B	FS-5306A	Input Shaft	
4301748	FS-6205A	Input Shaft	Use 3316171 Front Bearing Cover.
4301750	FS-6205A	Input Shaft	Use 4300888 or 4301144 Front Bearing Cover.
235433	FS-5005A	Input Shaft	Use 235357 Front Bearing Cover.
3315857	FS-4005A	Input Shaft	
3315536	FS-4005C	Input Shaft	Use 23147 or 3315538 Front Bearing Cover.
235648	FS-5005A	Input Shaft	Use 23147 or 235650 Front Bearing Cover.
3316257	FS-5106A	Input Shaft	Use 21992, 23106, 3316171 or 4301144 Front Bearing Cover.
21898	FS-5106A	Input Shaft	Use 3316171, 4300888 or 4301144 Front Bearing Cover.

4301825	FS-5205A	Input Shaft	Use 23147 Front Bearing Cover.
4301877	FS-5205A	Input Shaft	Use 23147 Front Bearing Cover.
S7064	FS-5205A	Kits & Assemblies	
S7063	FS-5205A	Kits & Assemblies	
14507	RT-11609A	Case (Front)	
K4148	F-5505B-DM3	Inertia Brake Assembly	
4305230	FAF-14810B	Case (Front)	
A4740-B	FAF-14810B	Filter Regulator	
K4150	F-5505B-DM3	Kits & Assemblies	
K4151	FAF-14810B	Kits & Assemblies	
A6058	RTLO-11118A-MT	Filter Regulator	
4304185	FRLO-15410C-T2	Countershaft & Bearings (Aux)	
4304184	FRLO-15410C-T2	Countershaft & Bearings (Aux)	
4300888	F-5505B-DM3	Case	
23147	FS-4005A	Case	Use 4300121 Oil Seal.
4301144	FS-5106A	Case	Use 4300121 Oil Seal.
235650	FS-5205A	Case	Use 4300204 Oil Seal.
237743	FS-4005A	Case	Use 4300798 Oil Seal.
238870	FS-4005A	Case	Use 4300798 Oil Seal.
239821	FS-4005A	Case	Use 4300798 Oil Seal.
4300882	FS-4005A	Case	Use 4300798 Oil Seal.
21992	FS-5106A	Case	Use 19110 Oil Seal.
21893	FS-5106A	Case	Use 4300798 Oil Seal.
21982	FS-5106A	Case	Use 4300798 Oil Seal.
3316313	FS-5106A	Case	Use 4300798 Oil Seal.
235357	FS-5205A	Case	Use 4300204 Oil Seal.
235358	FS-5205A	Case	Use 4300798 Oil Seal.
71205	AT-1202	Miscellaneous	
S1827	FS-4205A	Kits & Assemblies	
S1697	FS-5205A	Kits & Assemblies	
22384	FS-5205A	Lever Assembly	
5564543	EEO-18F112C	Lubricant	
71203	AT-1202	Miscellaneous	
S1440	RT-14915	Shift Bar Housing (RT)	
S1529R	RTF-14915	Shift Bar Housing (RTF)	
S2058R	RTL-13710B	Kits & Assemblies	
K4231RX	EH-8E306A-UPG	Kits & Assemblies	
4301473	EH-8E306A-UPG	Main Shaft Assembly	
10J14	EH-8E306A-UPG	Shift Bar Housing	
K4223RX	F-14E316B-LSE	Kits & Assemblies	
K3484	F-14E316B-LSE	Kits & Assemblies	
K3510	F-14E316B-LSE	Kits & Assemblies	
K3682	F-17E316B-LSE	Controller ECU & Harness	
A8690	F-17E316B-LSE	Range Cylinder	
K3365	F-17E316B-LSE	Range Cylinder	
K3980	F-17E316B-LSE	Shift Controls	
K1935-B	FAF-14810B	Kits & Assemblies	For A-5000 Valve.
K1935	FAF-14810B	Kits & Assemblies	For A-5000 Valve.

4306556	FO-10E310C-VAS	Countershaft Assembly	
K2934	FO-11E308LL-VCS	Countershaft Assembly	
4304073-B	FO-16D313E-LEP	Countershaft Assembly	
4304073	FO-16D313E-LEP	Countershaft Assembly	
K2923	FR-11210B	Kits & Assemblies	
K3407	FRLO-15410C-T2	Kits & Assemblies	
A7102	FRLO-15410C-T2	Range Cylinder	
K3264	FRO-11210C	Countershaft Assembly	
A5401	FS-4005A	Main Shaft Assembly	
A5693-B	FS-4005A	Main Shaft Assembly	
4300402	FS-4005A	Shift Bar Housing	
4300401	FS-4005A	Shift Bar Housing	
240324	FS-4005A	Shift Bar Housing	
4300429	FS-4005A	Shift Bar Housing	
A6609	FS-4205A	Main Shaft Assembly	
A6608-B	FS-4205A	Main Shaft Assembly	
A5692-B	FS-5106A	Main Shaft Assembly	
A5692	FS-5106A	Main Shaft Assembly	
3315778	FS-5106A	Shift Bar Housing	
3315777	FS-5106A	Shift Bar Housing	
A6135-B	FS-5306A	Main Shaft Assembly	
A6138	FS-5306A	Shift Bar Housing	
A6139	FS-5306A	Shift Bar Housing	
K7051-B	FS-5406N	Kits & Assemblies	
A7934-B	FS-5406N	Main Shaft Assembly	
A6136-B	FS-6205A	Main Shaft Assembly	
4301852	FS-6205A	Main Shaft Assembly	
3316210	FS-6205A	Shift Bar Housing	
3316207	FS-6205A	Shift Bar Housing	
A6234	FS-6205A	Shift Bar Housing	
K2802	RT-11109A-AT	Kits & Assemblies	
K1486	RT-11509	Filter Regulator	
K1431	RT-11609A	Kits & Assemblies	
K1450	RT-11609A	Kits & Assemblies	
K1699	RT-11609A	Kits & Assemblies	
K1432	RT-11613	Kits & Assemblies	
K2937	RT-14109A-ATS	Countershaft Assembly	
K2078	RT-14615	Kits & Assemblies	
K1433	RT-6610	Kits & Assemblies	
K2942	RTAO-11710C-AC	Countershaft Assembly	
K2297	RTL-13710B	Kits & Assemblies	
K3334	RTL-13710B	Kits & Assemblies	
4303682	RTLO-11610B	Range Cylinder	
K2958	RTLO-12713A	Countershaft Assembly	
K2809	RTLO-12713A	Kits & Assemblies	
K2804-B	RTLO-12713A	Kits & Assemblies	
K3594	RTLO-16713A-T2	Kits & Assemblies	
K2953	RTX-11609P	Countershaft Assembly	
17258X	RT-11613	Main Shaft & Synchro (Aux)	

4300830-B	FM-14D310B-LST	Main Shaft Assembly	
4300830	FM-14D310B-LST	Main Shaft Assembly	
19911	T-11607A	Main Shaft Assembly	
4300382	FO-16D313E-LEP	Main Shaft Assembly	
4300512	RTO-11607LL	Main Shaft Assembly	
4300383	RT-11109A-AT	Main Shaft Assembly	
4300384	RT-11109A-AT	Main Shaft Assembly	
20617	RT-6609	Main Shaft Assembly	
15976	RT-6610	Main Shaft Assembly	
20618	RT-6609	Main Shaft Assembly	
17434	RT-6610	Main Shaft Assembly	
4300385	RT-11109A-AT	Main Shaft Assembly	
20619	RT-6609	Main Shaft Assembly	
21666	RT-6610	Main Shaft Assembly	
4300386	RT-11109A-AT	Main Shaft Assembly	
14716	RT-11609A	Main Shaft Assembly	
17436	RT-6610	Main Shaft Assembly	
4300387	RT-11109A-AT	Main Shaft Assembly	
20621	RT-6609	Main Shaft Assembly	
17437	RT-6610	Main Shaft Assembly	
12128	2-A-92	Drive Gear Assembly	
7391	2-A-92	Drive Gear Assembly	
K1568	2-A-92	Kits & Assemblies	
14347	AT-1202	Air Shift Assembly	
17415	AT-1202	Air Shift Assembly	
3220	AT-1202	Air Shift Assembly	
14621	AT-1202	Air Shift Assembly	
4304602	AT-1202	Case (Aux)	
7992	AT-1202	Case (Aux)	
14335	AT-1202	Case (Aux)	
15532	AT-1202	Case (Aux)	
16784	AT-1202	Case (Aux)	
17106	AT-1202	Case (Aux)	
20224	AT-1202	Case (Aux)	
20226	AT-1202	Case (Aux)	
K3651	AT-1202	Case (Aux)	
K2262-B	AT-1202	Case (Aux)	
20225	AT-1202	Case (Aux)	Use with 20224 Plug or OEM Supplied Non-Adjustable Speedometer Sensor. Not to be used with 4301954 Seal.
13679	AT-1202	Case (Aux)	Use with OEM Supplied Adjustable Speedometer Sensor. Not to be used with 4301954 Seal.
S2151	AT-1202	Case (Aux)	
4301954	AT-1202	Case (Aux)	
7935	AT-1202	Case (Front)	

17179	AT-1202	Case (Front)	Use with Manual Shift.
4305309	AT-1202	Case (Front)	
4305310	AT-1202	Case (Front)	
22941	AT-1202	Case (Front)	
15899	AT-1202	Case (Front)	Use with Air Shift.
18128	AT-1202	Case (Front)	
14575	AT-1202	Case (Front)	
4302809	AT-1202	Case (Front)	
11364	AT-1202	Countershaft Assembly	
4303920	AT-1202	Input Shaft & Drive Gear	
17402	AT-1202	Input Shaft & Drive Gear	
17395	AT-1202	Input Shaft & Drive Gear	
17425	AT-1202	Input Shaft & Drive Gear	
18408	AT-1202	Input Shaft & Drive Gear	
17399	AT-1202	Input Shaft & Drive Gear	
K1479	AT-1202	Kits & Assemblies	
K1552	AT-1202	Kits & Assemblies	
15260	AT-1202	Main Shaft Assembly	
22254-B	AT-1202	Main Shaft Assembly	
22254	AT-1202	Main Shaft Assembly	
20191	AT-1202	Main Shaft Assembly	
3315659	EH-8E306A-UPG	Case	
K3411	EH-8E306A-UPG	Case	
4300119	EH-8E306A-UPG	Case	
3315679	EH-8E306A-UPG	Case	
201398	EH-8E306A-UPG	Case	
3316160	EH-8E306A-UPG	Case	
4301607	EH-8E306A-UPG	Case	
4304097-B	EH-8E306A-UPG	Countershaft Assembly	
4304542-B	EH-8E306A-UPG	Countershaft Assembly	
4303238	EH-8E306A-UPG	Countershaft Assembly	
K3795	EH-8E306A-UPG	Countershaft Assembly	
230292-B	EH-8E306A-UPG	Countershaft Assembly	
230292	EH-8E306A-UPG	Countershaft Assembly	
3315686	EH-8E306A-UPG	Countershaft Assembly	
12815	EH-8E306A-UPG	Cross Shaft Assembly	
K3438	EH-8E306A-UPG	Kits & Assemblies	
4303230	EH-8E306A-UPG	Main Shaft Assembly	
4303231	EH-8E306A-UPG	Main Shaft Assembly	
4304057	EH-8E306A-UPG	Main Shaft Assembly	
4301475	EH-8E306A-UPG	Main Shaft Assembly	
4304098-B	EH-8E306A-UPG	Main Shaft Assembly	
4304543	EH-8E306A-UPG	Main Shaft Assembly	
4301476	EH-8E306A-UPG	Main Shaft Assembly	
4301468	EH-8E306A-UPG	Main Shaft Assembly	
4301484	EH-8E306A-UPG	Main Shaft Assembly	
3315725	EH-8E306A-UPG	Main Shaft Assembly	

3315728	EH-8E306A-UPG	Main Shaft Assembly	
15900	EH-8E306A-UPG	Shift Bar Housing	
4300854	EH-8E306A-UPG	Shift Bar Housing	
227675-B	EH-8E306A-UPG	Shift Bar Housing	
3315772	EH-8E306A-UPG	Shift Bar Housing	
3315897	EH-8E306A-UPG	Shift Bar Housing	
4305452	EH-8E306A-UPG	X-Y Shifter Module	
4302320	F-14E316B-LSE	Case (Aux)	
4307247	F-14E316B-LSE	Case (Aux)	
K2918	F-14E316B-LSE	Case (Aux)	
1009551	F-14E316B-LSE	Case (Aux)	
4304653	F-14E316B-LSE	Case (Aux)	
K2805	F-14E316B-LSE	Case (Aux)	
S2501-B	F-14E316B-LSE	Case (Aux)	
S2501	F-14E316B-LSE	Case (Aux)	
4308226	F-14E316B-LSE	Case (Front)	
K4036	F-14E316B-LSE	Case (Front)	
A7471	F-14E316B-LSE	Case (Front)	
14311	F-14E316B-LSE	Case (Front)	
K4144	F-14E316B-LSE	Case (Front)	
13653	F-14E316B-LSE	Case (Front)	
13834	F-14E316B-LSE	Case (Front)	
13835	F-14E316B-LSE	Case (Front)	
5568544	F-14E316B-LSE	Case (Front)	
4304023-B	F-14E316B-LSE	Case (Front)	1-1/16" Magnetic, O-Ring Included.
4304023	F-14E316B-LSE	Case (Front)	1-1/16" Magnetic, O-Ring Included.
4306583	F-14E316B-LSE	Case (Front)	
4301851-BOX	F-14E316B-LSE	Countershaft & Bearings (Aux)	
K3220	F-14E316B-LSE	Countershaft & Bearings (Aux)	
4303124	F-14E316B-LSE	Countershaft & Bearings (Aux)	
4304765-B	F-14E316B-LSE	Countershaft Assembly	
4304765	F-14E316B-LSE	Countershaft Assembly	
4300247-B	F-14E316B-LSE	Countershaft Assembly	
4304840	F-14E316B-LSE	Countershaft Assembly	
19198	F-14E316B-LSE	Countershaft Assembly	
4302082	F-14E316B-LSE	Countershaft Assembly	
20840-B	F-14E316B-LSE	Countershaft Assembly	
20840	F-14E316B-LSE	Countershaft Assembly	
K1698	F-14E316B-LSE	Filter Regulator	
15114	F-14E316B-LSE	Filter Regulator	
K4145	F-14E316B-LSE	Kits & Assemblies	
K3902	F-14E316B-LSE	Kits & Assemblies	
K4143	F-14E316B-LSE	Kits & Assemblies	
K3492-B	F-14E316B-LSE	Kits & Assemblies	

K3497-B	F-14E316B-LSE	Kits & Assemblies	Sliding Clutch Included in Kit.
K3497	F-14E316B-LSE	Kits & Assemblies	Sliding Clutch Included in Kit.
62504	F-14E316B-LSE	Main Shaft Assembly	
4305996	F-14E316B-LSE	Main Shaft Assembly	
4303336	F-14E316B-LSE	Reverse Idler	
16757	F-14E316B-LSE	Reverse Idler	
17073	F-14E316B-LSE	Splitter Cylinder	
4303583	F-14E316B-LSE	Splitter Cylinder	
21208	F-14E316B-LSE	Splitter Cylinder	
21209	F-14E316B-LSE	Splitter Cylinder	
4306631	F-14E316B-LSE	Splitter Cylinder	
5566510-BOX	F-17E316B-LSE	Auxiliary Drive Gear	
4301254	F-17E316B-LSE	Auxiliary Drive Gear	
20509	F-17E316B-LSE	Integral Oil Pump	
K3367-B	F-17E316B-LSE	Integral Oil Pump	
14765	F-17E316B-LSE	Integral Oil Pump	
20823	F-17E316B-LSE	Integral Oil Pump	
14853	F-17E316B-LSE	Integral Oil Pump	
4305715	F-17E316B-LSE	Integral Oil Pump	
4303775	F-17E316B-LSE	Integral Oil Pump	
4301844	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
K4035	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
4306894	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
4301840-B	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
4301840	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
691934	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
4303424	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
4300912-B	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
4300912	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
14897-B	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
A7331-B	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
A7331	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
A7254-B	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
A7254	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
5556507	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
4300902-BOX	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
4304820	F-17E316B-LSE	Oil Filter	
691955	F-17E316B-LSE	Range Cylinder	
14344	F-17E316B-LSE	Range Cylinder	
14341	F-17E316B-LSE	Range Cylinder	
22823-B	F-17E316B-LSE	Range Cylinder	
20332	F-17E316B-LSE	Shift Bar Housing	
4302676	F-17E316B-LSE	Shift Bar Housing	
1634	F-17E316B-LSE	Shift Bar Housing	

14659	F-17E316B-LSE	Shift Bar Housing	
691600	F-17E316B-LSE	Shift Bar Housing	
691601	F-17E316B-LSE	Shift Bar Housing	
4300121	F-5505B-DM3	Case	
K2183	F-5505B-DM3	Kits & Assemblies	
4306043	F-5505B-DM3	Shift Controls	
16133	FA-15810B	Shift Bar Housing	
16134	FA-15810B	Shift Bar Housing	
16132	FA-15810B	Shift Bar Housing	
5566507-BOX	FAF-14810B	Auxiliary Drive Gear	
21342	FAF-14810B	Countershaft & Bearing (Aux)	
S1659-B	FAF-14810B	Kits & Assemblies	
S1659	FAF-14810B	Kits & Assemblies	
K1921	FAF-14810B	Kits & Assemblies	
K4217	FAF-14810B	Kits & Assemblies	
K3494-B	FAF-14810B	Kits & Assemblies	Sliding Clutch Included in Kit.
K3494	FAF-14810B	Kits & Assemblies	Sliding Clutch Included in Kit.
20323-B	FAF-14810B	Main Shaft & Synchro (Aux)	
22898	FAF-14810B	Main Shaft & Synchro (Aux)	
4302184	FAF-14810B	Main Shaft Assembly	
4302312	FAF-14810B	Main Shaft Assembly	
84003	FAF-14810B	Roadranger Valve/Slave Valve Tubing & Connectors	
85003	FAF-14810B	Roadranger Valve/Slave Valve Tubing & Connectors	
85001	FAF-14810B	Roadranger Valve/Slave Valve Tubing & Connectors	
5586100	FAF-14810B	Roadranger Valve/Slave Valve Tubing & Connectors	
A6909-B	FAF-14810B	Roadranger Valve/Slave Valve Tubing & Connectors	
84103	FAF-14810B	Roadranger Valve/Slave Valve Tubing & Connectors	
84102	FAF-14810B	Roadranger Valve/Slave Valve Tubing & Connectors	
8968	FAF-14810B	Shift Bar Housing	
10019	FAF-14810B	Shift Bar Housing	
14912	FAF-14810B	Shift Bar Housing	
15770	FAF-14810B	Shift Bar Housing	
6392	FAF-14810B	Shift Bar Housing	
14908	FAF-14810B	Shift Bar Housing	
14909	FAF-14810B	Shift Bar Housing	
14910	FAF-14810B	Shift Bar Housing	
19481	FAF-14810B	Slave Valve A-5000	
20490	FAF-14810B	Slave Valve A-5000	
A5000-B	FAF-14810B	Slave Valve A-5000	
A5000	FAF-14810B	Slave Valve A-5000	

K1969	FAF-14810B	Slave Valve A-5000	
21268	FAF-14810B	Slave Valve A-5000	
5566508-BOX	FAM-15810B-EA3	Auxiliary Drive Gear	
4300894	FAM-15810B-EA3	Auxiliary Drive Gear	
19063	FAO-14810C	Shift Bar Housing	
20120	FAO-14810C	Shift Bar Housing	
18928	FAO-14810C	Shift Bar Housing	
19062	FAOF-14810C	Shift Bar Housing	
16628	FM-14D310B-LST	Auxiliary Drive Gear	
K3760	FM-14D310B-LST	Case (Front)	
A6338	FM-14D310B-LST	Countershaft & Bearings (Aux)	
4308452	FM-14D310B-LST	Countershaft Assembly	
14317	FM-14D310B-LST	Countershaft Assembly	
K3637	FM-14D310B-LST	Inertia Brake	
20514	FM-14D310B-LST	Integral Oil Pump	
K1956	FM-14D310B-LST	Kits & Assemblies	
K2402	FM-14D310B-LST	Kits & Assemblies	
K3518	FM-14D310B-LST	Kits & Assemblies	
S2688-B	FM-14D310B-LST	Kits & Assemblies	
S2688	FM-14D310B-LST	Kits & Assemblies	
S1404	FM-14D310B-LST	Kits & Assemblies	
S2913	FM-14D310B-LST	Kits & Assemblies	
4302276-B	FM-14D310B-LST	Main Shaft & Synchro (Aux)	
4302276	FM-14D310B-LST	Main Shaft & Synchro (Aux)	
5556503-BOX	FM-14D310B-LST	Main Shaft & Synchro (Aux)	
4302092-B	FM-14D310B-LST	Main Shaft & Synchro (Aux)	
4302092	FM-14D310B-LST	Main Shaft & Synchro (Aux)	
4303620	FM-14D310B-LST	Main Shaft Assembly	
23653-B	FM-14D310B-LST	Main Shaft Assembly	
23653	FM-14D310B-LST	Main Shaft Assembly	
14749	FM-14D310B-LST	Main Shaft Assembly	
18025	FM-14D310B-LST	Oil Cooler	
18209	FM-14D310B-LST	Oil Cooler	
4303360	FM-14E310B-LAS	Auxiliary Drive Gear	
K4011	FM-14E310B-LAS	Kits & Assemblies	
4302090-B	FM-14E310B-LAS	Main Shaft & Synchro (Aux)	
4302090	FM-14E310B-LAS	Main Shaft & Synchro (Aux)	
A5474-B	FM-14E310B-LAS	Range Cylinder	
A5474	FM-14E310B-LAS	Range Cylinder	
4303357	FO-10E309ALL-VMS	Auxiliary Drive Gear	
A6844	FO-10E309ALL-VMS	Countershaft & Bearings (Aux)	
21352	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
4300677-B	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
4300677	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	

17332	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
A5156-B	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
A5156	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
21365	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
21652	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
4302468	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
4303673	FO-10E310C-VAS	Auxiliary Drive Gear	
A6339	FO-10E310C-VAS	Countershaft & Bearings (Aux)	
4303497	FO-10E310C-VAS	Main Shaft Assembly	
4303428-B	FO-10E310C-VAS	Main Shaft Assembly	
4303428	FO-10E310C-VAS	Main Shaft Assembly	
4301222	FO-10E310C-VAS	Main Shaft Assembly	
4302047-B	FO-10E310C-VAS	Main Shaft Assembly	
21332	FO-11E308LL-VCS	Combination Cylinder	
20423	FO-11E308LL-VCS	Combination Cylinder	
K2427	FO-11E308LL-VCS	Combination Cylinder	
A5159-B	FO-11E308LL-VCS	Combination Cylinder	
A5159	FO-11E308LL-VCS	Combination Cylinder	
A5160-B	FO-11E308LL-VCS	Combination Cylinder	
A5160	FO-11E308LL-VCS	Combination Cylinder	
K3500	FO-11E308LL-VCS	Countershaft & Bearings (Aux)	
4305052	FO-11E308LL-VCS	Countershaft Assembly	
21361	FO-11E308LL-VCS	Main Shaft & Synchro (Aux)	
21319-B	FO-11E308LL-VCS	Main Shaft & Synchro (Aux)	
21319	FO-11E308LL-VCS	Main Shaft & Synchro (Aux)	
4305051	FO-11E308LL-VCS	Main Shaft Assembly	
S3108	FO-16D313E-LEP	Kits & Assemblies	
4303705-B	FO-16D313E-LEP	Main Shaft & Synchro (Aux)	
4303705	FO-16D313E-LEP	Main Shaft & Synchro (Aux)	
A6888	FO-20E318B-MXP	Countershaft & Bearings (Aux)	
A5634	FO-6406A-ASX	Case	
K7028	FO-6406A-ASX	Kits & Assemblies	
K3422	FO-6406A-ASX	Kits & Assemblies	
K3436	FO-6406A-ASX	Kits & Assemblies	
K3245-B	FR-11210B	Air Module & Range Cylinder	
K3245	FR-11210B	Air Module & Range Cylinder	
K3129	FR-11210B	Air Module & Range Cylinder	
5554902	FR-11210B	Air Module & Range Cylinder	
14197	FR-11210B	Air Module & Range Cylinder	
15569	FR-11210B	Air Module & Range Cylinder	
K3128-B	FR-11210B	Air Module & Range Cylinder	
K3128	FR-11210B	Air Module & Range Cylinder	
4302080	FR-11210B	Air Module & Range Cylinder	
4302248	FR-11210B	Case (Aux)	
K4337	FR-11210B	Case (Aux)	
86104	FR-11210B	Case (Aux)	

A5992	FR-11210B	Case (Front)	#1 Pull Aluminum for Models above 1250 Lbs/ft.
A3713	FR-11210B	Case (Front)	#1 Push-Pull Iron.
A4772	FR-11210B	Case (Front)	#2 Push/Pull Aluminum.
A3723	FR-11210B	Case (Front)	#2 Push/Pull Iron.
20552	FR-11210B	Case (Front)	
5577509	FR-11210B	Case (Front)	
A6434	FR-11210B	Countershaft & Bearings (Aux)	
4304491-B	FR-11210B	Countershaft Assembly	
4304491	FR-11210B	Countershaft Assembly	
4303737-B	FR-11210B	Countershaft Assembly	
4303737	FR-11210B	Countershaft Assembly	
4302317	FR-11210B	Countershaft Assembly	
4302792-B	FR-11210B	Countershaft Assembly	For Models with Pump.
4302792	FR-11210B	Countershaft Assembly	For Models with Pump.
4302486	FR-11210B	Input Shaft & Drive Gear	Use with 4303999 Main Drive Gear.
4303362	FR-11210B	Input Shaft & Drive Gear	Use with 4304635 Main Drive Gear.
4303742	FR-11210B	Integral Oil Cooler	
K3246	FR-11210B	Integral Oil Cooler	
A6473-B	FR-11210B	Integral Oil Pump	
21767	FR-11210B	Isolators	
21236	FR-11210B	Isolators	
21235	FR-11210B	Isolators	
4301168	FR-11210B	Isolators	
K4054	FR-11210B	Kits & Assemblies	
K3602	FR-11210B	Kits & Assemblies	
K3883	FR-11210B	Kits & Assemblies	
K2910	FR-11210B	Kits & Assemblies	
K2921	FR-11210B	Kits & Assemblies	
K3150	FR-11210B	Kits & Assemblies	
S2790	FR-11210B	Kits & Assemblies	
S2822-B	FR-11210B	Kits & Assemblies	
S1794	FR-11210B	Kits & Assemblies	
K3399-B	FR-11210B	Kits & Assemblies	
K3399	FR-11210B	Kits & Assemblies	
K2429	FR-11210B	Kits & Assemblies	
K2428	FR-11210B	Kits & Assemblies	
K2978	FR-11210B	Kits & Assemblies	
K3376	FR-11210B	Kits & Assemblies	
K2003	FR-11210B	Kits & Assemblies	
K3507	FR-11210B	Kits & Assemblies	
S2809-B	FR-11210B	Kits & Assemblies	
S2809	FR-11210B	Kits & Assemblies	
S2680R	FR-11210B	Kits & Assemblies	

K1476	FR-11210B	Kits & Assemblies	
S2130-B	FR-11210B	Kits & Assemblies	
S2130	FR-11210B	Kits & Assemblies	
S2129-B	FR-11210B	Kits & Assemblies	
S2129	FR-11210B	Kits & Assemblies	
S2519-B	FR-11210B	Kits & Assemblies	
S2519	FR-11210B	Kits & Assemblies	
K2973	FR-11210B	Kits & Assemblies	
K2977	FR-11210B	Kits & Assemblies	
K3130-B	FR-11210B	Kits & Assemblies	
K3130	FR-11210B	Kits & Assemblies	
K3495-B	FR-11210B	Kits & Assemblies	Sliding Clutch Included in Kit.
K3495	FR-11210B	Kits & Assemblies	Sliding Clutch Included in Kit.
K3131	FR-11210B	Kits & Assemblies	
10427	FR-11210B	Levers/Housings	
4305294	FR-11210B	Levers/Housings	
18482	FR-11210B	Levers/Housings	
17600	FR-11210B	Levers/Housings	
6541	FR-11210B	Levers/Housings	3/8" used with 17167 Only.
18299	FR-11210B	Levers/Housings	
4303030	FR-11210B	Levers/Housings	
2538	FR-11210B	Levers/Housings	
S1677	FR-11210B	Levers/Housings	
2536	FR-11210B	Levers/Housings	
4302413-B	FR-11210B	Main Shaft & Synchro (Aux)	
4302413	FR-11210B	Main Shaft & Synchro (Aux)	
4303880-B	FR-11210B	Main Shaft Assembly	
4303880	FR-11210B	Main Shaft Assembly	
4302529-B	FR-11210B	Main Shaft Assembly	
4304001-B	FR-11210B	Main Shaft Assembly	
4304001	FR-11210B	Main Shaft Assembly	
4304617-B	FR-11210B	Main Shaft Assembly	
4304617	FR-11210B	Main Shaft Assembly	
4303033-B	FR-11210B	Main Shaft Assembly	
4303033	FR-11210B	Main Shaft Assembly	
4306650-B	FR-11210B	Main Shaft Assembly	
4306649	FR-11210B	Main Shaft Assembly	
4306650	FR-11210B	Main Shaft Assembly	
20400	FR-11210B	Miscellaneous	
4302156	FR-11210B	Shift Bar Housing (FR)	

4302159-B	FR-11210B	Shift Bar Housing (FR)	
4302159	FR-11210B	Shift Bar Housing (FR)	
4304604-B	FR-11210B	Shift Bar Housing (FR)	
4304604	FR-11210B	Shift Bar Housing (FR)	
4302749	FR-11210B	Shift Bar Housing (FR)	
4302175	FR-11210B	Shift Bar Housing (FR)	
4302142	FR-11210B	Shift Bar Housing (FR)	
4304138	FR-11210B	Shift Bar Housing (FR)	
4302748	FR-11210B	Shift Bar Housing (FR)	
4303038	FR-11210B	Shift Bar Housing (FR)	
4303037	FR-11210B	Shift Bar Housing (FR)	Can be used with Either 4305075 or 4302151 Shift Bar Housing.
4308006	FR-11210B	Shift Bar Housing (FR)	Can Only be used with 4305075 Shift Bar Housing.
4302166	FR-11210B	Shift Bar Housing (FR)	
4302183	FR-11210B	Shift Bar Housing (FR)	
4302139	FR-11210B	Shift Bar Housing (FR)	
4302134	FR-11210B	Shift Bar Housing (FR)	
4303135	FR-11210B	Shift Bar Housing (FR)	
4303117	FR-9210B	Reverse Idler	
4304186	FRLO-15410C-T2	Electronic Control Unit	
4304266	FRLO-15410C-T2	Input Shaft & Drive Gear	
5568545	FRLO-15410C-T2	Input Shaft & Drive Gear	
K4131	FRLO-15410C-T2	Kits & Assemblies	
K3764	FRLO-15410C-T2	Kits & Assemblies	
S2810	FRLO-15410C-T2	Kits & Assemblies	
K3617	FRLO-15410C-T2	Kits & Assemblies	
4304161	FRLO-15410C-T2	Main Shaft & Synchro (Aux)	
4304140	FRLO-15410C-T2	Main Shaft & Synchro (Aux)	
4304263	FRLO-15410C-T2	Main Shaft Assembly	
4304230	FRLO-15410C-T2	Main Shaft Assembly	
4304114	FRLO-15410C-T2	Main Shaft Assembly	
4304130	FRLO-15410C-T2	Main Shaft Assembly	
4304132	FRLO-15410C-T2	Main Shaft Assembly	
4304267	FRLO-15410C-T2	Main Shaft Assembly	
A7479	FRLO-15410C-T2	Shift Knob	
4304107	FRLO-15410C-T2	Shift Shaft Assembly	
A6927	FRLO-15410C-T2	Shift Shaft Assembly	
4304265	FRLO-15410C-T2	Shift Shaft Assembly	
5568529	FRLO-15410C-T2	Splitter Cylinder	
4305879-B	FRM-15210B	Countershaft Assembly	
4305879	FRM-15210B	Countershaft Assembly	
4306033	FRM-15210B	Countershaft Assembly	

4305880-B	FRO-11210B	Input Shaft & Drive Gear	Use with 4303362 Snap Ring and S-2822 Input Shaft.
4305880	FRO-11210B	Input Shaft & Drive Gear	Use with 4303362 Snap Ring and S-2822 Input Shaft.
K3419	FRO-11210B	Kits & Assemblies	
4304007	FRO-11210B	Main Shaft Assembly	
A6436-B	FRO-11210C	Countershaft & Bearings (Aux)	D/G 23160 - C/S 4302426.
A6436	FRO-11210C	Countershaft & Bearings (Aux)	D/G 23160 - C/S 4302426.
4302422-B	FRO-11210C	Countershaft Assembly	
4302422	FRO-11210C	Countershaft Assembly	
4303120	FRO-11210C	Countershaft Assembly	
4304641-B	FRO-11210C	Input Shaft & Drive Gear	
K3420-B	FRO-11210C	Kits & Assemblies	For Units Built Prior to 3-1-99.
K3420	FRO-11210C	Kits & Assemblies	For Units Built Prior to 3-1-99.
K4175	FRO-11210C	Kits & Assemblies	
S2844R	FRO-11210C	Kits & Assemblies	Includes Range Cylinder Assembly.
S2845R	FRO-11210C	Kits & Assemblies	Includes Range Cylinder Assembly and Optional Detent Spring Design Detent Spring. It is used to Increase Shifter Detent Force.
4303225	FRO-11210C	Shift Bar Housing (FRO)	
4302152	FRO-11210C	Shift Bar Housing (FRO)	
K3916	FRO-11210C	Shift Bar Housing (FRO)	
4304464	FRO-11210C	Shift Bar Housing (FRO)	
4302170	FRO-11210C	Shift Bar Housing (FRO)	Use with 4302150 Housing.
4304438-B	FRO-11210C	Shift Bar Housing (FRO)	Use with 4304435 Housing.
4304438	FRO-11210C	Shift Bar Housing (FRO)	Use with 4304435 Housing.
K4176	FRO-16210B	Kits & Assemblies	
S2847R	FRO-16210B	Kits & Assemblies	
4304622	FRO-17210C	Countershaft Assembly	
4304621	FRO-17210C	Main Shaft Assembly	
62516	FROF-11210B	Shift Bar Housing (FROF)	
A7513	FS-4005A	Case	
240321	FS-4005A	Case	
21937	FS-4005A	Case	
4300798	FS-4005A	Case	
4300204	FS-4005A	Case	
4300203	FS-4005A	Case	

239783	FS-4005A	Case	
4300846	FS-4005A	Case	
S7030	FS-4005A	Case	
K7039	FS-4005A	Case	
21555	FS-4005A	Case	
241017	FS-4005A	Countershaft Assembly	
241016	FS-4005A	Countershaft Assembly	
241018	FS-4005A	Countershaft Assembly	
240767	FS-4005A	Countershaft Assembly	
235416	FS-4005A	Input Shaft	
K2143	FS-4005A	Kits & Assemblies	
K2116	FS-4005A	Kits & Assemblies	
K2144	FS-4005A	Kits & Assemblies	
K2113	FS-4005A	Kits & Assemblies	
202484	FS-4005A	Lever Assembly	
4301958	FS-4005A	Lever Assembly	
23180	FS-4005A	Lever Assembly	
201054	FS-4005A	Lever Assembly	
201401	FS-4005A	Lever Assembly	
K7062	FS-4005A	Lever Assembly	
K7061	FS-4005A	Lever Assembly	
4300690	FS-4005A	Lever Assembly	
239787	FS-4005A	Main Shaft Assembly	
21545	FS-4005A	Main Shaft Assembly	
21547	FS-4005A	Main Shaft Assembly	
21546	FS-4005A	Main Shaft Assembly	
22079	FS-4005A	Main Shaft Assembly	
23694	FS-4005A	Main Shaft Assembly	
239651	FS-4005A	Main Shaft Assembly	
239818	FS-4005A	Main Shaft Assembly	
K3704	FS-4005A	Main Shaft Assembly	
239832	FS-4005A	Main Shaft Assembly	
224069	FS-4005A	Main Shaft Assembly	
240037	FS-4005A	Main Shaft Assembly	
235378	FS-4005A	Main Shaft Assembly	
228296	FS-4005A	Main Shaft Assembly	
3315687	EH-8E306A-UPG	Countershaft Assembly	
3315727	EH-8E306A-UPG	Main Shaft Assembly	
3312252	FS-4005A	Remote Control	
12F100	FS-4005A	Remote Control	
240022	FS-4005A	Reverse Idler Gear Assembly	
4301492	EH-8E306A-UPG	Main Shaft Assembly	
240038	FS-4005A	Shift Bar Housing	
14J1818	FS-4005A	Shift Bar Housing	
A6534	FS-4005A	Shift Bar Housing	
233794	FS-4005A	Shift Bar Housing	
4303939	FS-4005A	Shift Bar Housing	
241015	FS-4005C	Countershaft Assembly	
239815	FS-4005C	Main Shaft Assembly	
S7077	FS-4205A	Kits & Assemblies	

K3421	FS-4205A	Kits & Assemblies	
K3479	FS-4205A	Kits & Assemblies	
K7065	FS-4205A	Lever Assembly	
4301529-B	FS-4205A	Main Shaft Assembly	
4301529	FS-4205A	Main Shaft Assembly	
4301533	FS-4205A	Main Shaft Assembly	
4301528-B	FS-4205A	Main Shaft Assembly	
4303796-B	FS-4205A	Main Shaft Assembly	
4303796	FS-4205A	Main Shaft Assembly	
4303689	FS-4205A	Main Shaft Assembly	
4301532-B	FS-4205A	Main Shaft Assembly	
4301566	FS-4205A	Main Shaft Assembly	
A6326	FS-5005A	Countershaft Assembly	
235363	FS-5005A	Main Shaft Assembly	
4301183	FS-5005B	Countershaft Assembly	
4301186	FS-5005B	Countershaft Assembly	
4301182	FS-5005B	Countershaft Assembly	
K2085	FS-5005B	Kits & Assemblies	
K2294	FS-5005B	Kits & Assemblies	
K2291	FS-5005B	Kits & Assemblies	
S1643	FS-5005B	Kits & Assemblies	
K2132	FS-5005B	Kits & Assemblies	
235364	FS-5005B	Main Shaft Assembly	
235366	FS-5005B	Main Shaft Assembly	
239352	FS-5005B	Main Shaft Assembly	
239353	FS-5005B	Main Shaft Assembly	
235365	FS-5005B	Main Shaft Assembly	
235373	FS-5005B	Main Shaft Assembly	
235431	FS-5005B	Main Shaft Assembly	
4301184	FS-5005C	Countershaft Assembly	
4301187	FS-5005C	Countershaft Assembly	
239347	FS-5005C	Main Shaft Assembly	
19110	FS-5106A	Case	
21947	FS-5106A	Case	Use 4300119 Oil Seal.
3316278	FS-5106A	Case	Use 4300119 Oil Seal.
3316225	FS-5106A	Case	
4303240	FS-5106A	Countershaft Assembly	
3315747	FS-5106A	Countershaft Assembly	
K2181	FS-5106A	Kits & Assemblies	
K2111	FS-5106A	Kits & Assemblies	
S7035	FS-5106A	Kits & Assemblies	
S7036	FS-5106A	Kits & Assemblies	
K7026	FS-5106A	Kits & Assemblies	
K2017	FS-5106A	Kits & Assemblies	
K2257	FS-5106A	Kits & Assemblies	
3315700	FS-5106A	Main Shaft Assembly	

22075	FS-5106A	Main Shaft Assembly	
3315723	FS-5106A	Main Shaft Assembly	
3315715	FS-5106A	Main Shaft Assembly	
3315738	FS-5106A	Main Shaft Assembly	
3315698	FS-5106A	Main Shaft Assembly	
23301	FS-5106A	Main Shaft Assembly	
3315692	FS-5106A	Main Shaft Assembly	
3315694	FS-5106A	Main Shaft Assembly	
3313798	FS-5106A	Main Shaft Assembly	
3315702	FS-5106A	Main Shaft Assembly	
3315730	FS-5106A	Main Shaft Assembly	
4302398	F-14E316B-LSE	Main Shaft Assembly	
A6744	FS-5106A	Shift Bar Housing	
3315765	FS-5106A	Shift Bar Housing	
4301603	FS-5205A	Case	
22014	FS-5205A	Case	
4300852	FS-5205A	Case	
235655	FS-5205A	Case	
241705	FS-5205A	Case	
226331	FS-5205A	Case	
3314685	FS-5205A	Case	
4301691	FS-5205A	Countershaft Assembly	
4301185	FS-5205A	Countershaft Assembly	
4301181	FS-5205A	Countershaft Assembly	
224024	FS-5205A	Countershaft Assembly	
K7030	FS-5205A	Kits & Assemblies	
K2119	FS-5205A	Kits & Assemblies	
K7031	FS-5205A	Kits & Assemblies	
17560	FS-5205A	Lever Assembly	
4301688	FS-5205A	Main Shaft Assembly	
4301687	FS-5205A	Main Shaft Assembly	
4301686-B	FS-5205A	Main Shaft Assembly	
K3303	FS-5205A	Main Shaft Assembly	
K3389	FS-5205A	Main Shaft Assembly	
4301684	FS-5205A	Main Shaft Assembly	
235375	FS-5205A	Main Shaft Assembly	
4301689-B	FS-5205A	Main Shaft Assembly	
4301689	FS-5205A	Main Shaft Assembly	
4304466	FS-5205A	Main Shaft Assembly	
235372	FS-5205A	Main Shaft Assembly	
235374	FS-5205A	Main Shaft Assembly	
4303603	F-14E316B-LSE	Main Shaft Assembly	
203609	FS-5205A	Reverse Idler Gear Assembly	
228330	FS-5205A	Shift Bar Housing	
106358	FS-5205A	Shift Bar Housing	
A6535	FS-5205A	Shift Bar Housing	
204756	FS-5205A	Shift Bar Housing	
233384	FS-5205A	Shift Bar Housing	

4301777	FS-5205B	Main Shaft Assembly	
4301478	FS-5306A	Countershaft Assembly	
K7053	FS-5306A	Kits & Assemblies	
K7027	FS-5306A	Kits & Assemblies	
K7050	FS-5306A	Kits & Assemblies	
4303232	FS-5306A	Main Shaft Assembly	
4303233-B	FS-5306A	Main Shaft Assembly	
4303233	FS-5306A	Main Shaft Assembly	
4301477-B	FS-5306A	Main Shaft Assembly	
4304935	FS-5406N	Countershaft Assembly	
4304545-B	FS-5406N	Main Shaft Assembly	
4304944	FS-5406N	Main Shaft Assembly	
4304549	FS-5406N	Main Shaft Assembly	
3316202	FS-6205A	Countershaft Assembly	
3316200	FS-6205A	Countershaft Assembly	
3316198	FS-6205A	Countershaft Assembly	
3316194	FS-6205A	Countershaft Assembly	
3316196	FS-6205A	Countershaft Assembly	
4301763	FS-6205A	Main Shaft Assembly	
4301764	FS-6205A	Main Shaft Assembly	
21738	FS-6205A	Main Shaft Assembly	
21739	FS-6205A	Main Shaft Assembly	
21740	FS-6205A	Main Shaft Assembly	
21741	FS-6205A	Main Shaft Assembly	
3316321	FS-6205B	Countershaft Assembly	
4301760	FS-6205B	Main Shaft Assembly	
K7023	FS-6206A	Kits & Assemblies	
K7036	FS-6305A	Kits & Assemblies	
4304931	FS-6406N	Main Shaft Assembly	
22329	FS-8206A	Case	
23376	FS-8206A	Input Shaft	
20711	FS-8206A	Main Shaft Assembly	
20712	FS-8206A	Main Shaft Assembly	
4300853	FS-8206A	Shift Bar Housing	
21199	FS-8206A	Shift Bar Housing	
4301165	FS-8206A	Shift Bar Housing	
4301163	FS-8206A	Shift Bar Housing	
15919	FS-8206A	Shift Bar Housing	
1064	FS-8206A	Shift Bar Housing	
4302680	FSO-6406A	Shift Bar Housing	
4304323	FSO-6406A	Shift Bar Housing	
A6975	FSO-6406A	Shift Bar Housing	
A6974	FSO-6406A	Shift Bar Housing	
4300810	RT-11109A-AT	Air Sys-Range	
17453	RT-11109A-AT	Auxiliary Drive Gear	
20458	RT-11109A-AT	Input Shaft & Drive Gear	
K2439	RT-11109A-AT	Kits & Assemblies	

19202	RT-11109A-AT	Main Shaft & Synchro (Aux)	
4303185	F-17E316B-LSE	Auxiliary Drive Gear	
16756X	RT-11109A-AT	Main Shaft Assembly	
4301842	F-17E316B-LSE	Main Shaft & Synchro (Aux)	
22899	FAF-14810B	Main Shaft & Synchro (Aux)	
21347	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
21358	FO-10E309ALL-VMS	Main Shaft & Synchro (Aux)	
3315673	FO-6406A-ASX	Reverse Idler Gear Assembly	
19690	RT-11109A-AT	Range Cylinder	
14349	RT-11109A-AT	Range Cylinder	
5202	RT-11109A-AT	Reverse Idler	
4302243	FR-11210B	Main Shaft & Synchro (Aux)	
14367	RT-11109A-ATR	Main Shaft & Synchro (Aux)	
19281	RT-11109A-ATR	Main Shaft & Synchro (Aux)	
14327	RT-11109A-ATR	Main Shaft & Synchro (Aux)	
4302258	FR-11210B	Main Shaft Assembly	
K1661	RT-11509	Case (Front)	
16751	RT-11509	Countershaft Assembly	
16742	RT-11509	Filter Regulator	
55527	RT-11509	H&C with A-5000 Valve	
K3493	RT-11509	Kits & Assemblies	
4302259	FR-11210B	Main Shaft Assembly	
21262	RT-11608	Countershaft Assembly	
21026	RT-11608	Input Shaft & Drive Gear	
4300325	RT-11608	Main Shaft & Synchro (Aux)	
21023	RT-11608	Main Shaft Assembly	
K2309	RT-11609A	Auxiliary Drive Gear	
17097	RT-11609A	Case (Aux)	
16724	RT-11609A	Case (Aux)	
S2136	RT-11609A	Case (Aux)	
S2149	RT-11609A	Case (Aux)	
15758	RT-11609A	H&C with A-4688 Valve	
14361	RT-11609A	H&C with A-4688 Valve	
16978	RT-11609A	Input Shaft & Drive Gear	
20508	RT-11609A	Integral Oil Pump	
K1603	RT-11609A	Kits & Assemblies	For Auxiliary Section.
K2199	RT-11609A	Kits & Assemblies	
K3491	RT-11609A	Kits & Assemblies	
K2424-B	RT-11609A	Kits & Assemblies	
K2424	RT-11609A	Kits & Assemblies	
K3157	RT-11609A	Kits & Assemblies	
20192	RT-11609A	Main Shaft & Synchro (Aux)	
17109	RT-11609A	Main Shaft Assembly	
16118-B	RT-11609A	Main Shaft Assembly	
4302241	FR-11210B	Reverse Idler	
20399	RT-11609A	Miscellaneous	
16778	RT-11609A	Range Cylinder	
A6162	RT-11609A	Range Cylinder	
84101	RT-11609A	Range Valve	
84006	RT-11609A	Road Speed Governor	

84002	RT-11609A	Road Speed Governor	
84004	RT-11609A	Road Speed Governor	
85002	RT-11609A	Road Speed Governor	
12769	RT-11609A	Road Speed Governor	
18734	RT-11609A	Road Speed Governor	
84001	RT-11609A	Roadranger Valves	
5586104	RT-11609A	Roadranger Valves	
20209	RT-11609A	Shift Bar Housing (STD)	
16136	RT-11609A	Shift Bar Housing (STD)	
K1447	RT-11610	Kits & Assemblies	
K1451	RT-11610	Kits & Assemblies	
4302484	RT-11610	Non-Selective Main Shaft Assembly	
4300186	RT-11613	Case (Aux)	
K2430	RT-11613	Case (Aux)	
21426	RT-11613	H&C with 19470 VALVE	
55508	RT-11613	H&C with 19470 VALVE	
21427	RT-11613	H&C with 19470 VALVE	
21428	RT-11613	H&C with 19470 VALVE	
55509	RT-11613	H&C with A-4688 Valve	
K2315	RT-11613	Kits & Assemblies	
K1826	RT-11613	Kits & Assemblies	For A-4900 Valve.
K3193	RT-11613	Kits & Assemblies	For A-6913 Valve.
K2002	RT-11613	Kits & Assemblies	Complete - Range & Splitter for Enlarged Bore Size in Spltter Cylinder.
K1457	RT-11613	Kits & Assemblies	For Insert Valve.
K1644-B	RT-11613	Kits & Assemblies	
K1644	RT-11613	Kits & Assemblies	
K3331-B	RT-11613	Kits & Assemblies	
K3331	RT-11613	Kits & Assemblies	
K2013	RT-11613	Kits & Assemblies	
K1550	RT-11613	Kits & Assemblies	
A4738	RT-11613	Main Shaft & Synchro (Aux)	
4303859	RT-11613	Main Shaft & Synchro (Aux)	
14291	RT-11613	Main Shaft & Synchro (Aux)	
18135	RT-11613	Main Shaft & Synchro (Aux)	
18250X	RT-11613	Main Shaft & Synchro (Aux)	
4304128	FRLO-15410C-T2	Main Shaft Assembly	
4300764	RT-11613	Miscellaneous	
A6159	RT-11613	Range Cylinder	
A6913	RT-11613	Ratio Control	
82013	RT-11613	Selector Valves	
16961	RT-11613	Splitter Cylinder	Use with 17070 Cylinder.
21211	RT-11613	Splitter Cylinder	Use with 21210 Cylinder.
K1922	RT-11615	Kits & Assemblies	
K2015	RT-11615	Kits & Assemblies	
15959	RT-11615	Main Shaft & Synchro (Aux)	
17070	RT-11615	Reduction Cylinder	Use with 16962 Yoke Bar & Piston.

21210	RT-11615	Reduction Cylinder	Use with 21233 Yoke Bar & Piston.
14632	RT-11615	Reduction Cylinder	
19974	RT-11615	Reduction Cylinder	
15719	RT-11615	Reduction Cylinder	
16517	RT-11615	Reduction Cylinder	
21233	RT-11615	Reduction Cylinder	
A6915	RT-11615	Roadranger Valves	
21364	RT-11709A	Case (Aux)	
22900	RT-11709A	Case (Aux)	
22903	RT-11709A	Countershaft & Bearings (Aux)	
K2061	RT-11709A	Kits & Assemblies	
K3209-B	RT-11709A	Kits & Assemblies	
K3209	RT-11709A	Kits & Assemblies	
K2366	RT-11709A	Kits & Assemblies	
21355-BOX	RT-11709A	Main Shaft & Synchro (Aux)	
23023	RT-11709A	Main Shaft & Synchro (Aux)	
4306648	RT-11709H	Main Shaft Assembly	
20549	RT-11710B	Case (Front)	
K2327	RT-11710B	Kits & Assemblies	
21330	RT-11715	Combination Cylinder	
21329	RT-11715	Combination Cylinder	
21331	RT-11715	Combination Cylinder	
55528	RT-11715	H&C with 19470 VALVE	
K2077	RT-11715	Kits & Assemblies	
K2054-B	RT-11715	Kits & Assemblies	For Combination Cylinder.
K2054	RT-11715	Kits & Assemblies	For Combination Cylinder.
K2063	RT-11715	Kits & Assemblies	
21360-B	RT-11715	Main Shaft & Synchro (Aux)	
21360	RT-11715	Main Shaft & Synchro (Aux)	
235415	FS-4005A	Input Shaft	
14364	RT-12509	H&C with A-4688 Valve	
K1064	RT-12509	Kits & Assemblies	
A6160	RT-12509	Range Cylinder	
17386	RT-12515	Case (Aux)	
17252	RT-12515	Case (Aux)	
K1509	RT-12515	Kits & Assemblies	
18114	RT-12515	Main Shaft & Synchro (Aux)	
16945	RT-12515	Main Shaft Assembly	
16943	RT-12515	Main Shaft Assembly	
17245	RT-12515	Reduction Cylinder	
K1963	RT-12609A	Kits & Assemblies	
81057-B	RT-13609A	Countershaft & Bearings (Aux)	
20472	RT-13609A	Main Shaft & Synchro (Aux)	
K1800	RT-14609A	Kits & Assemblies	
K1962	RT-14613	Kits & Assemblies	
23181	FS-4005A	Lever Assembly	

15253	RT-14615	Countershaft & Bearings (Aux)	
4300312	RT-14709A	Main Shaft & Synchro (Aux)	
22969	RT-14709A	Main Shaft & Synchro (Aux)	
A6299-B	RT-14715	Case (Aux)	
A6299	RT-14715	Case (Aux)	
K2064	RT-14715	Kits & Assemblies	
21325-B	RT-14715	Main Shaft & Synchro (Aux)	
21325	RT-14715	Main Shaft & Synchro (Aux)	
K3671	RT-14910B-AS2	Case (Front) Forced Lube	
4303359-B	RT-14915	Main Shaft & Synchro (Aux)	
4303359	RT-14915	Main Shaft & Synchro (Aux)	
4300828-B	RT-15613	Countershaft & Bearings (Aux)	
4300828	RT-15613	Countershaft & Bearings (Aux)	
K1763	RT-15615	Kits & Assemblies	
K2098	RT-15615	Kits & Assemblies	
20604	RT-6609	Countershaft Assembly	
A5568	RT-6609	Input Shaft & Drive Gear	
A5498	RT-6609	Input Shaft & Drive Gear	
23418	RT-6609	Input Shaft & Drive Gear	
20833	RT-6609	Main Shaft Assembly	
21672	RT-6609	Main Shaft Assembly	
A4989	RT-6609	Main Shaft Assembly	
20614	RT-6609	Main Shaft Assembly	
20597	RT-6609	Main Shaft Assembly	
20615	RT-6609	Main Shaft Assembly	
23127	FS-4005A	Main Shaft Assembly	
240026	FS-4005A	Main Shaft Assembly	
240023	FS-4005A	Reverse Idler Gear Assembly	
3315704	FS-5106A	Main Shaft Assembly	
20622	RT-6609	Shift Bar Housing (STD)	
15748	RT-6610	Auxiliary Drive Gear	
15981	RT-6610	Auxiliary Drive Gear	
14993	RT-6610	Auxiliary Drive Gear	
15994	RT-6610	Auxiliary Drive Gear	
15061	RT-6610	Case (Aux)	
16240	RT-6610	Case (Aux)	
A3711	RT-6610	Case (Front)	
15491	RT-6610	Case (Front)	
15020	RT-6610	Case (Front)	
15059	RT-6610	Case (Front)	
15060	RT-6610	Case (Front)	
16020	RT-6610	Case (Front)	
19209X	RT-6610	Countershaft Assembly	
16662	RT-6610	Countershaft Assembly	
14286	RT-6610	Countershaft Assembly	
15050	RT-6610	Countershaft Assembly	
4300330	RT-6610	H&C with 19470 VALVE	
55517	RT-6610	H&C with 19470 VALVE	

55513	RT-6610	H&C with 19470 VALVE	
20649	RT-6610	H&C with 19470 VALVE	
15095	RT-6610	H&C with 19470 VALVE	
K2079	RT-6610	H&C with 19470 VALVE	
12751	RT-6610	H&C with A-4688 Valve	
15977	RT-6610	Input Shaft & Drive Gear	
S1255X	RT-6610	Input Shaft & Drive Gear	
S1251	RT-6610	Input Shaft & Drive Gear	
S1250	RT-6610	Input Shaft & Drive Gear	
15973	RT-6610	Input Shaft & Drive Gear	
15971	RT-6610	Input Shaft & Drive Gear	
K1931	RT-6610	Kits & Assemblies	
K1958	RT-6610	Kits & Assemblies	
K2444	RT-6610	Kits & Assemblies	
20835	RT-6610	Main Shaft & Synchro (Aux)	
4303687	FS-5205A	Main Shaft Assembly	
16772	RT-11109A-AT	Main Shaft & Synchro (Aux)	
A3990	RT-6610	Main Shaft Assembly	
15980	RT-6610	Main Shaft Assembly	
16403	RT-11109A-AT	Reverse Idler	
19466	RT-11109A-ATR	Main Shaft & Synchro (Aux)	
14330	RT-11509	Main Shaft & Synchro (Aux)	
21353	RT-11715	Main Shaft & Synchro (Aux)	
16315	RT-14613	Main Shaft & Synchro (Aux)	
15017	RT-6610	Range Cylinder	
15062	RT-6610	Range Cylinder	
15091	RT-6610	Range Cylinder	
15659	RT-6610	Range Cylinder	
15090	RT-6610	Range Cylinder	
15088	RT-6610	Range Cylinder	
15133	RT-6610	Shift Bar Housing (STD)	
15605	RT-6610	Shift Bar Housing (STD)	
15096	RT-6610	Shift Bar Housing (STD)	
15910	RT-6610	Shift Bar Housing (STD)	
15100	RT-6610	Shift Bar Housing (STD)	
22371	RT-7608LL	Auxiliary Drive Gear	
K2425	RT-7608LL	Auxiliary Drive Gear	
23064	RT-7608LL	Auxiliary Drive Gear	
23261	RT-7608LL	Countershaft & Bearings (Aux)	
K2110	RT-7608LL	Kits & Assemblies	
23101	RT-7608LL	Shift Bar Housing (STD)	
20579	RT-8609	Case (Front)	
20789	RT-8609	Case (Front)	
20635	RT-8609	Case (Front)	
20606	RT-8609	Countershaft & Bearings (Aux)	
20832	RT-8609	Countershaft Assembly	
A5030	RT-8609	Countershaft Assembly	
4301855	RT-8609	Input Shaft & Drive Gear	
A5022	RT-8609	Input Shaft & Drive Gear	Use with FBC 20777.

A5021	RT-8609	Input Shaft & Drive Gear	2" Pull. Use with FBC 20785.
21671	RT-8609	Input Shaft & Drive Gear	
20783	RT-8609	Main Shaft & Synchro (Aux)	
20593	RT-8609	Main Shaft Assembly	
S2928-B	RT-8709B	Input Shaft & Drive Gear	Use with FBC 20552.
S2928	RT-8709B	Input Shaft & Drive Gear	Use with FBC 20552.
K3352	RTAO-11710B-AC	Controller ECU & Harness	
K3281	RTAO-11710B-AC	Controller ECU & Harness	
K2839	RTAO-11710B-AC	Kits & Assemblies	
4302088	RTAO-11710B-AC	Main Shaft Assembly	
22032	RTAO-11710B-AC	Main Shaft Assembly	
4301220	RTAO-11710C-AC	Main Shaft Assembly	
23102	RTAO-11710C-AC	Main Shaft Assembly	
22943	RTF-11608	Shift Bar Housing (F)	
75120	RTL-13710B	Hoses & Connections	
75320	RTL-13710B	Hoses & Connections	
K2347	RTL-13710B	Kits & Assemblies	
K2298	RTL-13710B	Kits & Assemblies	
S1786	RTL-13710B	Kits & Assemblies	
4303432	RTL-13710B	Levers/Housings	
A6910-B	RTL-13710B	Roadranger Valves	
A6910	RTL-13710B	Roadranger Valves	
4301553	RTL-13710B	Shift Bar Housing (STD)	
22803	RTL-13710B	Shift Bar Housing (STD)	
S2107	RTL-14710B	Case (Aux)	
4300904	RTL-14710B	Main Shaft & Synchro (Aux)	
5586113	RTLC-16609E	13 Speed Roadranger Valve	
21607	RTLC-16609E	13 Speed Splitter Cylinder	
4300182	RTLC-16609E	13 Speed Splitter Cylinder	
A6163	RTLC-16609E	Range Cylinder	
K3189	RTLO-11118A-MT	Auxiliary Drive Gear	
4300184	RTLO-11118A-MT	Countershaft & Bearings (Aux)	
S2660	RTLO-11118A-MT	Kits & Assemblies	
4302059-B	RTLO-11118A-MT	Main Shaft & Synchro (Aux)	
4302059	RTLO-11118A-MT	Main Shaft & Synchro (Aux)	
4302058	RTLO-11118A-MT	Main Shaft & Synchro (Aux)	
21931	RTLO-11118A-MT	Main Shaft & Synchro (Aux)	
A6340-B	RTLO-11118A-MT	Main Shaft & Synchro (Aux)	
A6340	RTLO-11118A-MT	Main Shaft & Synchro (Aux)	
21930-B	RTLO-11118A-MT	Main Shaft & Synchro (Aux)	
21930	RTLO-11118A-MT	Main Shaft & Synchro (Aux)	
21589	RTLO-11118A-MT	Main Shaft Assembly	
21587	RTLO-11118A-MT	Main Shaft Assembly	
A7318	RTLO-11118A-MT	Roadranger Valves	
A6918	RTLO-11118A-MT	Roadranger Valves	
21760	RTLO-11118A-MT	Splitter Cylinder	
K2640	RTLO-11610B	Auxiliary Drive Gear	
A6387	RTLO-11610B	Countershaft & Bearings (Aux)	

K3243	RTLO-11610B	Countershaft Assembly	
K3121	RTLO-11610B	Hoses & Connections	
4302695	RTLO-11610B	Main Shaft & Synchro (Aux)	
4301400	RTLO-11610B	Main Shaft & Synchro (Aux)	
K3315	RTLO-11610B	Main Shaft Assembly	
K3333	RTLO-11610B	Splitter Cylinder	
K2295	RTLO-11610B-T2	Kits & Assemblies	
K3198	RTLO-11610B-T2	Kits & Assemblies	
4303969	RTLO-11610B-T2	Main Shaft Assembly	
4300911	RTLO-12713A	Auxiliary Drive Gear	
A6756-B	RTLO-12713A	Countershaft & Bearings (Aux)	C/S 4303648 - D/G 4300935 S/G 4300936.
A6756	RTLO-12713A	Countershaft & Bearings (Aux)	C/S 4303648 - D/G 4300935 S/G 4300936.
K2804	RTLO-12713A	Kits & Assemblies	
K3151	RTLO-12713A	Kits & Assemblies	
A8030	RTLO-12713A	Main Shaft & Synchro (Aux)	
4300907-B	RTLO-12713A	Main Shaft & Synchro (Aux)	
4300907	RTLO-12713A	Main Shaft & Synchro (Aux)	
4304317-B	RTLO-12713A	Main Shaft Assembly	
4304317	RTLO-12713A	Main Shaft Assembly	
4301847	RTLO-12713A	Range Cylinder	
A6188-B	RTLO-12713A	Range Cylinder	
S1445	RTLO-12713A	Shift Bar Housing	
S1527R	RTLO-12713A	Shift Bar Housing	
18922-B	RTLO-12713A	Shift Bar Housing	
18922	RTLO-12713A	Shift Bar Housing	
4305575-B	RTLO-12713A	Shift Bar Housing	
4305575	RTLO-12713A	Shift Bar Housing	
K4336	RTLO-12913A	Case (Aux)	
K3676	RTLO-12913A	Case (Front) Forced Lube	#1 Pull Aluminum.
K3672	RTLO-12913A	Case (Front) Forced Lube	#1 Pull Iron. Nodal Mount. Upper/Lower.
K3288	RTLO-12913A	Kits & Assemblies	
K3341	RTLO-12913A	Kits & Assemblies	
S2910R	RTLO-12913A	Kits & Assemblies	
K3327	RTLO-12913A	Kits & Assemblies	
4303649-B	RTLO-12913A	Main Shaft & Synchro (Aux)	
4303649	RTLO-12913A	Main Shaft & Synchro (Aux)	
4302376	RTLO-14610A	Main Shaft & Synchro (Aux)	
4300124	RTLO-14610A	Main Shaft & Synchro (Aux)	
22940	RTLO-14610A	Shift Bar Housing (STD)	
83001	RTLO-14613B	Roadranger Valves	
83002	RTLO-14613B	Roadranger Valves	
83501	RTLO-14613B	Roadranger Valves	
83502	RTLO-14613B	Roadranger Valves	

K2617	RTLO-14618A	Main Shaft & Synchro (Aux)	
4306624	RTLO-14713A	Main Shaft & Synchro (Aux)	
A6224-B	RTLO-14718B	Range Cylinder	
A7011-B	RTLO-14718B	Splitter Cylinder	
A7011	RTLO-14718B	Splitter Cylinder	
K3967	RTLO-14918A-AS2	Kits & Assemblies	
K3202	RTLO-16713A	Countershaft & Bearings (Aux)	
4302662	RTLO-18913A	Input Shaft & Drive Gear	
4304084	RTLO-20913A	Auxiliary Drive Gear	
K3458	RTLO-20913A	Kits & Assemblies	
4304086-B	RTLO-20918B	Main Shaft & Synchro (Aux)	
4304086	RTLO-20918B	Main Shaft & Synchro (Aux)	
S2890	RTLO-22918A-AS2	Input Shaft & Drive Gear	
K3538	RTLOC-16909A-T2	Kits & Assemblies	
S1528R	RTLOF-12713A	Shift Bar Housing	
K3758	RTO-10910B-DM2	Kits & Assemblies	
21021	RTO-11109A-ATS	Input Shaft & Drive Gear	
21073	RTO-11109B-ATE	Case (Aux)	
A4728	RTO-11109B-ATE	Countershaft & Bearings (Aux)	
19239X	RTO-11109B-ATE	Input Shaft & Drive Gear	
S2917	RTO-11607LL	Input Shaft & Drive Gear	
S1661	RTO-11607LL	Input Shaft & Drive Gear	2" Pull. Use with FBC 20550.
16396	RTO-11607LL	Input Shaft & Drive Gear	
S1131X	RTO-11607LL	Kits & Assemblies	
4300290	RTO-11607LL	Main Shaft Assembly	
4300975	RTO-11607LL	Main Shaft Assembly	
A3456	RTO-11607LL	Main Shaft Assembly	
S1781	RTO-11607LL	Main Shaft Assembly	
23139	RTO-11607LL	Main Shaft Assembly	
14289	RTO-11607LL	Main Shaft Assembly	
15086	RT-6610	Main Shaft & Synchro (Aux)	
19792	RTO-11607LL	Shift Bar Housing (STD)	
4300536	RTO-11607LL	Shift Bar Housing (STD)	
19793	RTO-11607LL	Shift Bar Housing (STD)	
19791	RTO-11607LL	Shift Bar Housing (STD)	
19838	RTO-11607LL	Shift Bar Housing (STD)	
20465	RTO-11608LL	Miscellaneous	
K2489	RTO-11707DLL	Kits & Assemblies	
K2853	RTO-11709MLL	Kits & Assemblies	
4302451	RTO-11709MLL	Main Shaft Assembly	
15776	RTO-11709MLL	Shift Bar Housing	
4302517	RTO-11709MLL	Shift Bar Housing	
17121	RTO-12510	Input Shaft & Drive Gear	
16674	RTO-12510	Main Shaft Assembly	
K1993	RTO-15618	Kits & Assemblies	
21670	RTO-6610	Main Shaft Assembly	
K3501	RTOCM-16909A	Kits & Assemblies	
4302494	RTOF-11709MLL	Shift Bar Housing	

21499	RTX-11609P	Countershaft Assembly	
21497	RTX-11609P	Countershaft Assembly	
21498	RTX-11609P	Main Shaft Assembly	
22963	RTX-11609P	Main Shaft Assembly	
22743	RTX-11609R	Main Shaft Assembly	Use with 16118 SL Clutch and 14749 Spacer.
23014	RTX-11609R	Main Shaft Assembly	Use with 22026 SL Clutch and 22032 Spacer.
4300035	RTX-16709H	Main Shaft & Synchro (Aux)	
K1782	T-11605D	Kits & Assemblies	
S1220	T-11605D	Kits & Assemblies	
18364	T-11605D	Output Shaft	
14754	T-11605D	Output Shaft	
8270	T-11605D	Reverse Idler	
20817	T-11607A	Case (Aux)	
62515	T-11607A	Case (Front)	
K1846	T-11607A	Kits & Assemblies	
19909	T-11607A	Main Shaft Assembly	
19910	T-11607A	Main Shaft Assembly	
16798	T-11607A	Main Shaft Assembly	
4303199	T-11607A	Main Shaft Assembly	
16247	RT-6610	Main Shaft & Synchro (Aux)	
21214	T-14607A	Input Shaft & Drive Gear	
4304541-B	EH-8E306A-UPG	Countershaft Assembly	
4306033-B	FRM-15210B	Countershaft Assembly	
K3681	FM-14D310B-LST	Kits & Assemblies	
K3638	F-5505B-DM3	Inertia Brake Assembly	
20507	RT-11609A	Integral Oil Pump	
4303409-B	RT-11609A	Non-Selective Main Shaft Assembly	
4303409	RT-11609A	Non-Selective Main Shaft Assembly	
20794	RT-6609	Main Shaft Assembly	
4303435	RTO-11909MLL	Main Shaft Assembly	
14373	AT-1202	Case (Front)	
4301474	EH-8E306A-UPG	Main Shaft Assembly	
3315696	FS-5106A	Main Shaft Assembly	
4308403-B	F-14E316B-LSE	Reverse Idler	
4306632	F-14E316B-LSE	Splitter Cylinder	
21609	RTL-14710B	Splitter Cylinder	
K1010	RT-11613	Kits & Assemblies	
52601	RTL-13710B	Hoses & Connections	