

A quick and simple procedure that refills your master cylinder reservoir and/or hydraulic clutch reservoir with new fluid when bleeding a hydraulic system. Fluid feeder adapter fits most pint and quart brake fluid bottles (1-1/4" wide mouth). Also Included are three master cylinder reservoir adapter plates.

INSTRUCTIONS

For replacing old fluid with new when bleeding your system:

1. Screw feeder adapter onto brake fluid bottle.
2. Select the appropriate master cylinder plate and place it on top of the master cylinder reservoir.
3. Invert bottle of fluid with feeder adapter attached and insert feeder adapter into hole in the master cylinder plate. Push down on the feeder adapter until locks into the feeder plate (see illustration).
4. Bleed the hydraulic system as recommended by the manufacturer.

NOTE: Take care when inserting and removing brake fluid bottle to avoid spillage.

