





The following upgrade guide is in relation to updating the firmware by copying an update file to the SD card via the supplied USB cable. Our Dash Cams can also be updated via [My Nextbase Player](#)® (NBDVR222 and above).

	Windows	Mac
1. Download the latest version of firmware for the NBDVR222 via the Support & Downloads page for your Dash Cam.		
2. The firmware update will be saved to your PC as a file called 'FW222A. This will usually be located within the downloads folder on your computer. NOTE: You won't be able to open this file on your PC.		
3. Right click (CTRL & click if using a mac) on the bin files inside the Downloads folder and select the option that says 'Copy'		
4. Go to the Dash Cam Setup Menu (Press the Menu button twice when the camera is not recording) and select the option that says 'Format SD Card', press the 'OK' button to confirm.		
5. Plug the Dash Cam into your PC using the supplied USB cable and press the 'OK' button to select the 'Firmware Update' option.		
6. The Dash Cam should then appear as a storage device called 'NEXTBASE' within File Explorer (Windows) or Finder (Mac).		

<p>7. Click on your SD card as it appears within File Explorer/ Finder to view the contents of the card.</p>		
<p>8. Once the contents of the card are displayed, right click in the white space and select the option that says 'Paste'. This will copy the file from your downloaded zip file and place it onto the SD card where it can be read by the Dash Cam.</p>		
<p>9. Please ensure that the bin file is not renamed in anyway, the update will fail if the file appears as FW222A(1).bin for example.</p>		
<p>10. Once you have copied 'FW222A.bin' to the Dash Cam you can now unplug the Dash Cam from your PC. It will shut down and you will see the Nextbase logo.</p>		
<p>11. After the Dash Cam has shut down completely, plug it back into your PC and select 'Power On'. The update should begin automatically.</p>		
<p>12. After the update has installed your Dash Cam will restart and display the PC Connection Screen. Select the 'Power On' option using the 'OK' button to continue.</p>		
<p>13. After the Dash Cam has restarted open the Setup Menu (by pressing the 'Menu' button twice) and scroll down to 'System Info'. Press the 'OK' button to select this option and the Firmware version will be displayed.</p>		