



INSTALLATION INSTRUCTIONS

Failure to follow these instructions can severely shorten the life of this part and may void the part's warranty.

Installation Process

If you are replacing the Original Equipment Coil, you may have to destroy the original attachment devices to remove the coil. If this is the case, you will have to supply bolts, nuts and lock washers to install the replacement coil.-

Recommended: Two (2) each of: #8-36 x 1.25 hex flanged bolt; #8 lock washer and #8-36 flanged nut.

Models covered:

50007

IS17 – 4-29-09