

ELECTRONIC FUEL INJECTION TEST LIGHT

Tests electronic fuel injection systems on GM TBI, Bosch PFI, Ford TBI, GM PFI, Geo TBI and GM SCPI, equipped vehicles

1. Disconnect harness connector from injector.
2. Plug test light into connector and start engine.
Flashing light indicates electrical system is functioning correctly.
Steady light or no light indicates malfunctioning electrical system.
If problem persists, check fuel system.

Noid Lights:

W85101	GM TBI
W85102	Bosch PFI
W85103	Ford TBI
W85104	GM PFI
W85105	Geo TBI
W85106	GM SCPI

