USER'S MANUAL



Bluetooth°



BLUETOOTH® DOUBLE-DIN DVD/MP3/CD AM/FM RECEIVER FEATURING 6.75" (171 mm) CAPACITIVE TOUCHSCREEN










Thank you for choosing Planet Audio!

IMPORTANT! Fill Out And Keep For Your Records.



Contents

Contents	2
Notes	4
Cautions	5-7
About this Manual	7
California Prop. 65	7
Basic Product Operation	8
What comes in the box	
Product Basics	
Using/Caring for the Touchscreen	13
Product Setup	14
Navigating the Menus	15
Apple CarPlay	16
Warnings	16
Using CarPlay	16
Gestures & Control	16

CarPlay Display	17
Disable Apps	17
Android Auto	18
Warnings	18
Using Android Auto	18
Bluetooth®	19
Cautions	19
Setup & Connections	19
Phonebook	19
Device Status	19
Calling	20
History	20
Private Mode	20
Audio	21
Track Control	21

Media Player Source Switching	2
Media	22
Warnings	22
USB Playback	22
Navigating Menu	22
Photos	22
DVD Playback	23
Radio	2
Display Overview	2
Display Overview	
	2
Controls	2
Controls	2 2

Contents

AV IN	25
Playback	25
Camera	25
Warnings	25
Reverse View	25
General Settings	26
Cautions	26
System Language	26
Time Zone	26
Date & Time	26
Auto Adjust Daylight Saving	26
System Tone	26
Power Off Delay	26
Parental Disc Lock	26
Audio	27
EQ	27
Balance/Fader	27
Subwoofer	27
Loudness	27
Internal Amp	27
Volume	27
Source level	27

Display Settings	28
Illumination Control	28
Gamma	28
LED Touch Buttons	28
LED Brightness	28
LED Animation	28
User Interface	28
Bluetooth® Settings	29
Device Name	29
Camera	29
Rear Camera input	
	29
Rear Camera input	29
Rear Camera input	29 29 29
Rear Camera input Rear View pelay Radio Settings	29 29 29
Rear Camera input Rear View pelay Radio Settings Region	29292929292929

Connections	30
Cautions & Warnings	30-35
Power/SWC/MIC	30
Speaker	3
Audio Pre-amp/AV IN/ Radio	32
Camera/USB	3
Parking Brake	3
Hands-free Mic	35
Troubleshooting	36
Specifications	3

Important

This symbol with "WARNING" is intended to alert the user to the presence of critical instructions/procedures. Failure to observe the instructions/procedures can result in injury, death, damage to the product and/or property.



This symbol with "CAUTION" is intended to alert the user to the presence of important instructions/procedures. Failure to observe the instructions/procedures can result in injury or damage to the product and/or property.







Use of the Apple CarPlay logo means that a vehicle user interface meets Apple performance standards.

Apple is not responsible for the operation of this vehicle or its compliance with safety and regulatory standards. Please note that the use of this product with iPhone or iPod may affect wireless performance.

ipone is trademark of Apple Inc.,registered in the U.S.and other countries.

Apple CarPlay is a trademark of Apple Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Planet Audio is under license.

Other trademarks and trade names are those

of their respective owners

Caution

Precautions

BE SURE TO OBSERVE THE FOLLOWING GUIDELINES: Do not turn up the volume so high that you can't hear what's around you.

Use caution or temporarily discontinue use in potentially hazardous situations.

Do not operate mobile video equipment while driving a motorized vehicle – safe driving and safety consideration of others should always be your highest priority.

Set your volume control at a low setting, then slowly increase the sound until you can hear it comfortably without distortion, or ear discomfort.

In the event you should notice smoke, strange noises or odor from this product, or any other abnormal signs, immediately turn off the power and consult your dealer or the nearest authorized *Planet Audio* Service Center.

Using this product in this condition may result in permanent damage to the system.

Installation Precautions

Planet Audio does not recommend to install the product yourself.

We recommend to have it professionally installed by a certified professional.

Always consult with a professional installer .

Do not attempt to install or service this product by yourself. Installation or servicing of this product by persons without professional training and experience in electronic equipment and motorized vehicle accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards

Refer any repairs to a qualified Planet Audio Service Center

Caution

Before Installing

To avoid potential shorts in the electrical system, be sure to disconnect the (–) battery cable before installation.

Use this unit with a 12-volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.





Product Safety

It is against Federal and Local laws for video to be viewed by the driver while the vehicle is in motion. This video product was intended to be used with the parking brake safety feature. Video cannot be seen without the proper parking brake powered connection. Tampering or disabling this feature will void any and all warranty. Please check with a professional installer to have your product installed properly.



Important Note

Due to ongoing enhancements, example images on screens may slightly differ from actual product.

Caution

Images and Video

Watching video while driving is against Federal, State, and Local laws.

Drive safely, know and obey traffic rules. Watching this screen and making selections while driving can lead to a serious accident.

Check surroundings for safety while camera images are displayed.

Do not use features of this product while driving if it cannot be operated safely and legally in your location. Before operation of smartphone Apps accessible from this device, read safety instructions in your Owner's Manual. When using navigation Apps stay alert to observe real world conditions.

About this manual

To entirely understand how to properly use your new Planet Audio product, it is recommended to read this entire user's manual, and keep it in a safe place for future reference.

- -Read the entire manual
- -Keep the manual
- -Follow all instructions
- -Clean with a dry cloth only
- -Do not use or operate near water
- -Do not defeat any safety features

California Residents (Proposition 65)

This product may contain chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

What comes in the box

Hardware

Qty 1 P9950CPA

Qty 1 Trim Ring

Qty 1 Mounting Hardware Set

-M5 x 6mm Bolts (8)


-Brackets (2)

Connections


Qty 1 Power/Harness


Qty 1 Hands-free Microphone

Qty 1 Remote control










Remote Control Operation



- 1).POWER ON/OFF
- (2).EQ mode
- ③.EJECT Key
- 4.CLK Key
- (5).MODE Key
- 6.MENU Key
- (7).Audio KEY
- 8.SUBTITLE Changing Key
- 9.Direction and OK Key
- (10).MUTE Key
- (11).REPEAT Key
- (12).Play/Pause
- (13).ROOT Key
- (14).TITLE Key
- (15).Under Disc/music/video mode,press to choose previous/next song.
- 16. VOLUME UP/DOWN Key
- 17. Receiving calls/call out; hang up.
- 18.STOP/C/BAND
- (19). Number Key

Front Detail



1 Eject Button


2 Mute/Power

3 Siri Button

4 Volume Control

5 System Reset


Rear Detail



Product Basics

Eject

1. Touch to eject the disc



Mute

1. Touch to Mute

Siri

-Touch to command



CarPlay must be active



Power On /Standby

- 1. Touch once to Power ON
- 2. Touch and Hold for Standby



NOTE

In Standby Mode, the LED will slowly pulse on and off.



Volume

- 1. **Touch** once on either "+" / " -"
- 2. Touch and Hold for quicker operation



Using and Caring for the Touchscreen



Use:

This head unit utilizes a Capacitive Touchscreen, the same type that is used on high-end mobile devices. It should be used for and cared for like that type of device. As with all capacitive type technology, if your fingers are wet or sweaty, it will not function properly.

Do not allow any sharp objects to come in contact with the screen glass.

Care and Cleaning:

To clean the screen, use a dry microfiber type cloth to clean. Do not use ammonia, window cleaner, or any other type of household chemicals to clean the screen. Abrasives should not be used at all.

Product Setup (Date & Time)


Setup Option A: CarPlay Method

Connect your Apple ® device using a Lightning® cable*. The CarPlay USB port must be used.


This will automatically setup the time and date.

User must set Time Zone manually.

Default is Pacific Time Zone




Setup Option B: Date and Time



Additional Setup

General > Language
Audio > EQ, Other Audio Settings
Display > Illumination, Brightness, LED

Navigating the Menus



Apple CarPlay

Using CarPlay



1 Note

Apple CarPlay usage is limited while driving. Functions, contents, and usability is determined by the App provider(s).

Controls will vary with each App that is available for CarPlay.

For more details visit:

http://www.apple.com/ios/carplay



WARNING

Familiarize yourself with your Local and State laws regarding mobile devices.

Certain functions of an iPhone might be prohibited and or illegal while driving in your location.

When in doubt, park the vehicle and engage the parking brake first before performing the function(s).

Connecting to CarPlay USB Port

- Connect the CarPlay compatible device via LIGHTING ® cable (not included).
- 2. The iPhone will load the CarPlay function.
- On the display, the CarPlay will illuminate green, touch it to enter the CarPlay menu.
- 4. To return to the product **Home** menu,

Touch





NOTE


The product's Bluetooth will turn **OFF** automatically when CarPlay is in use. Hands-free phoning will function through the CarPlay feature.

When using CarPlay, there is no need to pair your iPhone, the USB cable connected through the USB Port (1) will enable this feature.

If other devices are connected via Bluetooth, they will be disconnected for the duration of CarPlay use.

Gestures & Control

Basic controls, but not limited to:





Other gestures and controls might differ on each App.



NOTE

Volume control is handled exclusively by the product.

Apple CarPlay

Using CarPlay

CarPlay Display Setup

1. Using your iPhone:

Settings > General > CarPlay

2. Touch and Hold each App icon to move.


To remove an App, Touch

Planet Audio P9950CPA



(i) NOTE

Only Apps with the icon can be removed from CarPlay.
Only Apps with the icon can be added in carplay.



How to Disable Apps

Using your iPhone:

Settings > Notifications > App to Disable



Android Auto

Using Android Auto



i Note

Android Auto usage is limited while driving.

Functions, contents, and usability is determined by the App provider(s).

Controls will vary with each App that is available for Android Auto.



Familiarize yourself with your Local and State laws regarding mobile devices.

Certain functions of the mobile device might be prohibited and or illegal while driving in your location.

When in doubt, park the vehicle and engage the parking brake first before performing the function(s).



NOTE

To complete the setup properly, the Parking Brake status wire must be connected.



For your safety, the setup process **MUST** be accomplished while the vehicle is **Parked and Parking Brake Engaged**.

Android Auto App

1. Using your Android device, download the **Android Auto** app on Google Play.





Minimum Requirements:

Android 5.0 Lollipop

Updating Related Apps

1. During the first start up and setup of the Android Auto app, the Maps, Music, Google apps will install/update automatically.

Connecting to Android Auto USB Port

- Connect the Android compatible device via the appropriate USB cable (not included).
- The Android device will load the Android Auto function.
- 3. Bluetooth will connect automatically when the setup is completed.

Android Auto Permissions Permissions

Several features can be allowed or denied access to customize your usability of the product.

The access can always be modified in Settings on the Android device.

Bluetooth®

Setup & Connection

Hands-Free Menu

Touch





NOTE

CarPlay must not be active. If being used, disconnect the iPhone to start Bluetooth.

Compatibility with all mobile devices is not guaranteed. Please read through the user's guide of the mobile device.



For your safety, the setup process should be accomplished while the vehicle is parked and parking brake engaged.

First time Pairing

Using your phone, media or other Bluetooth device, try to connect to this headunit.

Mobile Device:

Search for Planet Audio P9950CPA

iOS Devices: Settings > Bluetooth

Android Devices: **Settings > Connections > Bluetooth**

A passcode is generated and will display on both the head unit and mobile device for secure pairing.

Touch




to confirm

Every time the product is powered ON, the mobile device will automatically connect if within range.



NOTE

Once paired and connected, the device list will display the available Bluetooth profiles.



Phonebook and History

To Download Phonebook:

1. Touch Contact > Download

To Download History

1. Touch **History > Download**

Device Status

Battery and Cellular Strength is displayed on the top right of the Home menu.

GATT Profile support is required on the mobile device.



Bluetooth®

Hands-Free

Calling

Making & Receiving Calls

1. Dialing from the dial pad

Touch



to make call

2. Contacts

Touch the contact name

3. History

Choose the name, then

To **End** a call **Touch**



To **Mute** a call **Touch**



Dial pad

To use the dial pad while on a call

Touch



Searching History

Swipe Up or Down to search



History

Outgoing Call



Missed Call



Private Mode

When a call needs to be transferred to the mobile device:

Touch



to switch the mobile device

Touch



to return to hands-free mode

Searching Contacts

Contacts must be downloaded to search.

1. Touch



2. Enter the Contact Name, then

OK

Connection: **ON**Auto Connect: **ON**

Auto Answer: OFF

Device Name: Planet Audio P9950CPA

Clear Records

Bluetooth®

Audio

Audio Streaming

To play media through Bluetooth, the mobile device must be **Paired and Connected** to the P9950CPA

1. Touch



The music will play automatically.

Track Control

Play/Pause



2. Track Fwd / Rev

3. Swipe to Fwd/Rev



(i

Note

For best performance, your mobile device volume setting should be set to maximum.

All volume adjustments for the system should be controlled from the product.

The unit will recall the last volume setting on your mobile device every time is connects.

Formats

Playback is supported from the mobile device with any format it can play.

Audio will only be played by the product.

Video cannot be viewed on the unit.

Switching Media

Touch



Available sources will display (Bluetooth and USB)



Note

USB source will only be displayed if a USB drive is inserted and has playable media.

Display

Track info will be displayed when available.

Track, Album and Artist.

Album art is not supported via Bluetooth playback.

Media

USB

USB Playback

Touch



The music will play automatically.

Audio Control

- .. Play/Pause 📐
- 2. Track Fwd / Rev
- 3. Repeat List
- Repeat File
- 5. Random

(i) Note

If there are other files in the USB, music files will play first.

Video Control

- 1. Play/Pause > |
- 2. Track Forward/Backward
- 3. Repeat All
- 4. Repeat one
- 5. SETUP

Photo Control

- 1. Play/Pause \
- 2. Track Forward/Backward
- 3. Repeat All
- 4. Repeat One
- 5. Rotate

Navigating Menu

Touch



To browse contents Swipe



To return to the current file playing,

Touch III Playing



Watching videos or photos while driving is against Federal, State, and Local laws.

Do not use features of this product if it cannot be operated safely and legally in your location.



Note

Review the connections of this product, to properly integrate the parking brake wire to the vehicle.

Video and or photos cannot be viewed while driving. The vehicle must be stationary and the parking brake applied to enable viewing.

Media

DVD

DVD Playback

Touch



CD Audio Control

- 1. Music List
- . Track Fwd/Rev
- 3. Play/ Pause > 📗
- 4. Repeat all
- 5. Repeat one



Note

If there are other files in the USB, music files will play first.

DVD Video Control

- 1. Track Fwd/Rev
- 2. Track Previous/Next :touch and hold
- 3. Play/ Pause 🖒 |
- 4. Open/Close the navigation button
- 5. Subtitle language
- 6. Tools bar P.>
- 7. Select Chapter C1/2
- 8. Select Title **T3/3**
- 9. Repeat All, Repeat One and Repeat Off
- 10. Subtitle language or sub off
- 11.Viewing angle
- 12.Brightness/Contract/Color



13. Hidden the tools bar



Direct search

- 1.Touch the button P.>
- 2.Touch the button **C1/2** or **T3/3** to select a chapter or title directly using the on-screen display direct entry menu display. Enter the Direct Search menu,
- 3.Enter the chapter or Title Digital, touch \checkmark that starts the function.



WARNING

Watching videos while driving is against Federal ,State, and Local laws.

Do not use features of this product if it cannot be operated safely and legally in your location.



Note

Review the connections of this product, to properly integrate the parking brake wire to the vehicle.

Video and cannot be viewed while driving. The vehicle must be stationary and the parking brake applied to enable viewing.

Radio

AM/FM

Controls

Touch



Tuning

To search for stations:

Search

Touch and Hold

Manual Seek



Auto Search & Store: Touch (4)



Note

RBDS info (if available) and currently tuned station will display on the radio icon in the home screen

Not all stations will have or display RBDS info.



Band & Settings

Touch FM to switch bands

To change radio settings



Favorites and Presets

Settings Favorites



To remove a favorite, **Touch**



Browsing Favorites



To return the Tuner screen Touch



Changing Presets

Touch 🔀 🔀

To list all Stored Stations



Stereo/Mono

To turn on/off stereo when receiving a stereo signal,

Touch OO

LOC/DX

To select Local or Distant broadcasting stations,

Touch ((†))((+))

AV In/Camera

External Source

Playback

Touch



Media must be controlled from the external device.

Track functions are not controlled from the product.



Note

To adjust the volume level properly, the carry-in device volume should be set between 50% - 75%. The volume level should remain at that level for the remainder of the time it is connected to the product.



WARNING

Never rely solely on the rear view camera; always check your surroundings before proceeding.

Images may appear reversed

Do not use features of this product if it cannot be operated safely and legally in your location.

Rear View

The rear view camera can by displayed on demand.

Touch



To return to the Home screen

Touch



Reverse View

When the vehicle is put into reverse gear, the camera will display the image on the screen.



Rear View Delay

Due to varying vehicle configurations, the rear view trigger can be delayed to best suit the vehicle.

Default setting: **0 Sec** Delay



Note

The rear view camera will still function normally, if the product is in standby mode

Settings

General

System Language

to change

English (Default), Spanish

Note

CarPlay is independent of the system language setting.

Time Zone

Adjust to correctly display time

Default Setting: (GMT-08:00) Pacific Time (US&Canada)

Date & Time

24H Mode



Auto Adjust Daylight Saving



Note

If using an CarPlay, the iPhone will automatically set date & time. Time Zone needs to be adjusted manually.

System Tone



Power Off Delay

Some vehicles during crank to start will interrupt the accessory power.

If the product re-boots during crank to start, Turn **ON** delay

The delay can select 1, 2 or 3 sec.

Default Setting: OFF



Note

Power Off Delay **ON** will also delay when the vehicle is turned OFF.

This might affect hands-free functionality during a call.

Parental Disc Lock

Touch to select parent control level.

Factory Settings

To restore settings to default:





Will restore all settings to factory defaults.

All settings and presets will be lost.

Setting


Audio

EQ

To access the EQ menu

Touch







Note

The EQ can also be directly accessed while changing the volume. The volume display will show the EQ icon, you can touch to access the Audio Settings.



Preset EQ

Jazz, HipHop, Pop,Rock, R&B

Balance/Fader

Left/Right Balance, Touch



Swipe for quick adjustment



Front/Rear Fader, Touch



Swipe for quick adjustment

Subwoofer

The level and filter can be adjusted for the Sub pre-amp output.



Filter: 50Hz, 80 Hz, 120 Hz, 160 Hz

Touch +/- Subwoofer Frequency

Loudness

Enhances and gently boosts low and high freq.



Internal Amp

To reduce the possibility of noise entering the signal chain when utilizing the audio pre-amp outputs, the internal amp can be turned **OFF**



Volume

Settings are for default volumes for Main(Radio, Media), Hands-free(BT Ring, BT Talking), Apple CarPlay/Android Auto (Navi, Voice).

Source Level

The source mode(Radio, USB, BT Audio, AV Input, Apple carplay, Andriod Auto) Disc gain control.

Settings

Display **Bluetooth**

Illumination Control

Touch



When the vehicle lights are on, the products illumination can be customized for night use.

Gamma

Gamma can be adjusted for both day and night settings.

Screen Brightness

Swipe



LED Touch Buttons



Six preset colors can be chosen for Touch buttons, or chose below...



LED Brightness

Swipe 4

Brightness can be adjusted for both day and night settings.

LED Animation

Touch



Will cycle through all colors on LED touch buttons.

Default Setting: ON

UI settings

Wall paper

Touch to change

User can change the background picture by inserting a USB with photos.

Background Brightness

Connection

Touch



Power On/Off Bluetooth Default Setting: ON



Note

Bluetooth will turn OFF automatically when CarPlay is in use. If other devices are connected via Bluetooth, they will be disconnected for the duration of CarPlay use.

Auto Connect

Touch



Auto connects to the device when the product is powered ON

Default Setting: ON

Auto Answer



Auto answers when there is an incoming call.

Default Setting: OFF

Settings

Bluetooth Camera Radio

Device Name Planet Audio P9950CPA

Rear Camera input


Turn on if you have a rear view camera, turn off if you have not.

Parking Assist guide

Turn off if your rear view camera have parking assist guide, turn on if you have not.

Parking Assist guide Adjust

You can adjust parking assist guide



Rear View Delay

0 Sec (Default), 0.1 Sec, 0.5 Sec, 1 Sec, 2 Sec When switching from Park to Drive, or vice versa, the camera should not trigger on the display.

Sensitivity should be adjusted to trigger only on reverse gear selector.

Region

Touch

Default Setting: USA 2

US Tuner Spacing: FM (200 KHz), AM (10 KHz) European Spacing: FM (50 KHz), AM (9 KHz)

RBDS, Radio Broadcast Data System

Touch &

Default Setting: ON

Allows data from the radio station to be displayed on the product.

RBDS, Cont'd

Not all stations will broadcast information to display.

AF (Alternative Frequency)

Touch





When **On**, the tuner will automatically locate the same tuning program on other stations and select the strongest signal of those being broadcast.

Default Setting: OFF

TA (Traffic Announcement)

Touch



The radio will automatically tune in to traffic information broadcasts while receiving FM broadcasts playing media.

Default Setting: OFF

Power/SWC/MIC




CAUTION

It is recommended to have the product installed by a certified installation professional.




CAUTION

Before installation, or wiring connections, disconnect the negative (-) battery terminal to prevent damage to the product, and/or possible injury.






Remote Out is 500 mA max output rating. If several amplifiers are to be used, it is recommended to use a relay for the Remote Out trigger.



i Note

Unused input/output wires need be insulated with tape, heat shrink, or crimp connectors. Never use wire nuts.



Note

A separate interface might be needed for your vehicle application. It is recommend that you consult with a professional installer.



Note

Speakers



CAUTION

Do not chassis ground any speaker wire leads.



CAUTION

Only use 4-8 Ω Speakers

Do not use 1-3 Ω Speakers



CAUTION

Do not bridge any of the channels, they are only to be wired in stereo mode.





i Note

Unused speaker wires need be insulated with tape, heat shrink, or crimp connectors.

Never use wire nuts.

If the speaker outputs are not used, turn **Off** the internal amp to reduce the possibility of noise entering the signal chain.







Observe speaker polarity when making connections.

Audio Pre-amp/AV IN/ Radio




Subwoofer Pre-amp is a non-fading mono output.




Note

Always run signal wires away from power cables to reduce the possibility of noise.



i Note

If pre-amp outputs are being used exclusively, turn Off the internal amp of the product, to reduce the possibility of noise entering the signal chain.




Camera / USB



Never rely solely on the rear view camera; always check your surroundings before proceeding.

Images may appear reversed

Do not use a feature of this product if it cannot be operated safely and legally in your location.



Parking Brake



WARNING

Improper connection or use of the parking brake status wire, (i.e. defeating the safety feature) violates Federal, State, and Local laws. This may lead to injury, property damage, and/or death.



WARNING

Watching videos or photos while driving is against Federal, State, and Local laws.



For Andoird Auto setup, the parking brake status wire **MUST** be connected.




Note

Review the connections of this product, to properly integrate the parking brake wire to the vehicle.

Video and or photos cannot be viewed while driving. The vehicle must be stationary and the parking brake applied to enable viewing.





(i) Note

The parking brake input needs to be connected to the power side of the parking brake.

(i) Note

Every vehicle has a different type of parking brake connection; consult a certified professional installer.

Hands-free Mic

Placement

Every vehicle will perform differently due to layout, interior materials, etc...


The **Red** shaded areas are the recommended locations for best microphone performance.

Items to look for before placement:

- 1. Do not place in front of air vents.
- If the vehicle has tweeters placed on sail panels, do NOT locate the mic on steering column area.
- Front of mic must not be blocked.
- 4. Mic should be firmly attached to mounting location.
- 5. Do not cover the grille openings surrounding the mic.
- To avoid excessive wind noise, do not place near the sunroof opening



Run microphone wire where it will **NOT** impede the operation of any safety items, i.e. Airbags, Knee Airbags, etc...



Troubleshooting

Issues	Cause	Solution
No Sound	Internal amplifier is off	Go to Settings > Audio > Internal Amp
	Product is muted	Touch the volume.
	External amplifiers	Check the external amplifiers are on.
		Check the remote output wire has voltage
	Audio source	Change the audio source
Media Not Supported	Media on USB flash drive	Change the media format on the USB device
		Change the USB device
Bad Radio Reception	Radio area	Change the station
'	Naulo al ea	Turn OFF AF and TA
		Turn OFF RBDS
	Antenna	Antenna output wire isn't connected
	,e	Connect Antenna to product
Apple CarPlay/Anroid Auto will not start	Bad Lightning®/USB cable	Replace the cable
.,	Locked device	Device needs to be unlocked
	Not charged	Device needs to be powered Android Auto to function. Allow it to charge
	0.1	Android Auto to function. Allow it to charge and power on.
	CarPlay/Android Auto frozen	Unplug the device, close all Apps and plug it in
	,	again.
Bluetooth	Not connecting to device	Make sure the device is within range.
	-	Devices' Bluetooth connection needs to be turned ON

Troubleshooting

Issues	Cause	Solution
Bluetooth	Not connecting to device	Go to Setting >Connection >Power ON Pair and Connect the device like new.
Hands-free call quality	Mobile device	Check cellular strength on mobile device. End call and redial number.
	Microphone	Microphone placement needs to be relocated
		Microphone needs to be firmly attached to location it's mounted on.
		Check to see if microphone is properly plugged in.
Unit is unresponsive	Processor has frozen	Press the RESET button on the front panel
D'	Disc is dirty or wet	Clean the disc
Disc	Disc is scratched or warped	Use a new one in good condition
	Disc is upside down	Insert Disc in right way
	Unsupported Disc type Illegal mechanism operation	Check the disc and change Press EJECT for 5s to reset loading mechanism

Specifications

General
Power Input8.5 V—18 V DC
Nominal14.4 V DC
Current Consumption15A
Fuse Type15A
Dimensions (H x W x D)3.9" x 7" x 5"
Unit Weight2.43 lbs.
Operational Temperature4—158°F
Display
Screen Size6.75"
Aspect Ratio16 x 9
Resolution480 x 800
Screen TypeTFT-LED Active Matrix
Audio
Max Power80 W x 4 Ch.
Acceptable Speaker Load4-8 Ω
Preset EQ5
EQ Bands, Adjustable10
JAZZ, HIPHOP, POP, ROCK, R&B
32, 63, 125, 250Hz, 500Hz
1KHz, 2KHz, 4KHz, 8KHz, 16KHz
EQ Boost/Cut± 6 dE

Audio Cont'd Pre-amp Output......3 Pairs Front......4V, Full-Range Rear.....4V, Full-Range Sub (Mono)......4V, LPF Sub LPF......50 Hz. 80 Hz. 120 Hz. 160 Hz Sub Level.....+1-14dB **Radio Tuner** Freq. Range.....87.5 MHz-108 MHz (FM) Freq. Range......522 kHz-1710 kHz (AM) USA 1 Range (FM).....100 kHz Spacing USA 2 Range (FM).....200 kHz Spacing Europe Range (FM).....50 kHz Spacing RBDS......AF. TA **Apple CarPlay** iPhone Support.....iPhone 5 or Newer

iOS.....iOS 7.1 or Newer

Disc ...CD/CD-R/CD-RW/DVD/DVD±R/DVD±RW

DVD

Android Auto

USB
USB SpecUSB 2.0 (High-Speed)
USB Current Output1.5 A (Max)
File SystemFAT32
Audio PlaybackWAV, MP3
Video PlaybackAVI, MKV, WMV
Picture PlaybackJPG, PNG, BMP

Supported.....(5.0) Lollipop or Newer

*Not all listed compressed files guaranteed to play due to different creation methods or file contents.

Bluetooth®

Versionv4.2+E.D.F
Audio CodecS.B.G
Profiles
HEP v1.6.A2DP v1.2.AVRCP v1.5.PBAP v1.1