

## 250 Series - Flange Mount Kit

Mount the 250 Series (flange mount) bracket in a location that is easily accessible and safe from external damage (posts, forklifts, tire caps, etc.).

The secondary bracket is optional. It can be used to suspend the main bracket if desired.




**Attention:** DO NOT drill or cut mounting holes in the main chassis or any other part of the vehicles main framework unless it is approved by the manufacturer. Drilling holes without approval may void your warranty with the vehicle manufacturer.



**Attention:** The gauge must be mounted vertically. DO NOT mount on an angle or sideways.



**Attention:** ALWAYS install (or remove) the gauge using a wrench on the hex fitting only. Do not attempt to tighten (or loosen) by turning the housing or any other part of the gauge.



**Attention:** ALWAYS use a thread sealant to ensure leak-free operation.

**Right Weigh**  
Load Scales

