INSTRUCTIONS

CAUTION: DO NOT LET THE TESTER TOUCH ANY HOT ENGINE SURFACES (MANIFOLDS, ENGINE BLOCK, ETC.). KEEP TESTER AND YOUR BODY AWAY FROM MOVING ENGINE PARTS. DAMAGE, FIRE AND/OR INJURY MAY RESULT. TO DISCONNECT FROM THE SPARK PLUG, PULL ON THE RUBBER BOOT, NOT THE WIRE OR THE PLASTIC HOUSING.

I. INSTALLATION

- 1. Turn engine off.
- 2. Remove wire from spark plug.
- 3. Push female connector of In-Line Spark Checker onto spark plug.
- 4. Push the long male end of In-Line Spark Checker into spark plug wire.
- 5. Start engine.
- 6. Repeat above steps for all of the spark plugs.

II. TESTING

- CONDITION Engine does not start; bulb of In-Line Spark Checker is FLASHING.
 - INTERPRETATION The fuel system is most likely at fault.
- CONDITION Engine does not start; bulb of In-Line Spark Checker DOES NOT FLASH.
 - **INTERPRETATION** Ignition system component(s) faulty.
- CONDITION Engine starts; bulb is flashing but not at a constant rate.
 INTERPRETATION Dirty or fouled spark plugs; weak ignition system component(s).
- CONDITION Flashes are weak and are not constant as RPM of engine is increased.
 INTERPRETATION – Weak ignition system component(s).

FOR IGNITION SYSTEM PROBLEMS. CHECK THE FOLLOWING:

- A. Faulty distributor cap
- B. Faulty distributor rotor
- C. Faulty spark plug wire(s)
- D. Fouled, broken or incorrectly gapped, spark plug
- E. Faulty ignition module; D.I.S. Module
- F. Faulty pick-up coil
- G. Faulty ignition coil or coil pack
- H. Faulty condenser
- Faulty or incorrectly set distributor points

FOR MORE TROUBLE SHOOTING INFORMATION, REFER TO THE VEHICLE SERVICE MANUAL.

III. BULB REPLACEMENT

USE S&G PART NO. 23904 OR GE PART NO. NE51H(B2A)
UNSCREW KNURLED RETAINER FROM END OF CLEAR PLASTIC
BODY. REMOVE BULB FROM CONTACT SPRING. REPLACE WITH
NEW BULB BY SLIDING CONTACT SPRING OVER GLASS OF BULB
WITH A GENTLE CLOCKWISE TWISTING MOTION. INSTALL NEW
BULB AND SPRING INTO CLEAR PLASTIC BODY SO THAT BOTTOM
OF BULB FACES KNURLED RETAINER. SCREW KNURLED RETAINER
BACK INTO CLEAR PLASTIC BODY.