

HALOGEN LIGHT KIT INSTALLATION INSTRUCTIONS

1. Remove the main ground wire from negative side of the battery terminal.
2. Install lights on to mounting tab or surface.
3. Attach relay to inside of engine compartment using provided sheet metal screw.
Leave room around relay to run wiring and to service if needed.
4. Connect relay into wiring harness assembly.
5. Attach black wires to frame or sheet metal from wiring harness to create a ground.
6. Connect white wire plug of harness to white wire of light.
7. Connect white wire plug of harness to black wire of light.
8. In the same female terminal as above insert the two foot long power lead for the second light using like colored wires.
9. Mount switch so that illuminated indicator can be seen from drivers position.
10. Run white switch lead from relay to dash mounted switch.
11. Connect switch wire plug to the switch.
12. Connect the red wire into the head light power wire using the quick connector provided.
13. Connect white wire with the in line fuse from wiring harness assembly and attach it to the positive side of the battery terminal.
14. Reconnect the main ground wire to the battery terminal.
15. Lights should now operate properly.
16. If lights do not light up properly check the following—
 - a. Recheck all steps of the installation to the instructions.
 - b. Check in line fuse near relay.
 - c. Inspect fuse box for blown fuse.
 - d. Check ground wires for proper grounding.

WIRING DIAGRAM

