

Leaf Spring Pin Socket

15100 / 15101 / 15102 / 15103 / 15104 / 15105 / 15106

**TIGER
TOOL**

Have What It Takes

Safety Warning

Read all instructions and safety warnings prior to operation. Failure to do so could result in equipment damage, personal injury or even death.

- **Stay Alert!** Watch what you are doing and use common sense when operating this tool.
- Inspect product for damage prior to using; do not use if product is in unsafe condition.
- Do not operate tool while under the influence of drugs, alcohol or medication.
- Always use safety equipment to prevent injuries. Approved face and eye protection must always be worn by the operator, as well as others in the work area.
- Do not overreach. Keep proper footing and balance at all times.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts.
- Keep hands clear of all pressurized hydraulic components.
- Always ensure hoses are free from sharp bends and kinks.
- Keep your work area clean and well lit.

Operating Instructions

- 1 Select correct socket according to pin size.
- 2 Place socket onto pin.
- 3 Use impact tool to thread out pin.
- 6 Remove socket.



When it comes to quality suspension and steering service tools, Tiger Tool is the brand you can depend on.