## DIMMER CONTROL SWITCH WITH REMOTE

1. Connect the wires from LED light strip to the output side of dimmer. Positive to positive and negative to negative.

2. Connect a wire from positive input to the power source. This is normally the power wire described in the full installation instructions that came with your order. Connect the negative wire from input to a chassis ground source. If you have the 12V plug accessory simply connect the positive and negative together on input side.

When you try to adjust the brightness with remote make sure you hold the button down. You will not notice a change if you just press the button once.

Positive

from LED

