



# INSTALLATION INSTRUCTIONS FOR 370 SERIES BEEP BEEP HORN


## MOUNTING

Locate an area in the engine compartment that is dry and safe from the engine's exhaust manifold heat. The horn's front grill should be angled facing downward to prevent water from entering into the horn.

## WIRING (Fig. A)

**IMPORTANT:** Use 18 gauge wire or heavier for all connections.

Connect a wire to one of the horn's terminals. Connect the other end of the wire to (+) 12-volts battery, alternator or accessories. A 10-ampere fuse must be installed as shown in Fig.A, (FUSE NOT INCLUDED WITH HORN). Connect a wire to the horn's other terminal. Connect the other end of the wire to the horn switch. The other horn switch terminal is connected to ground, ( any body bolt that is clean of paint and rust).



Ground to any metal body bolt  
that is clean of paint and rust.