



# PRE-TREATMENT CUT THRU SYSTEM



- Prevents corrosion
- Promotes adhesion
- For use on metal surfaces
- Substitutes the use of wash, etch, and epoxy primers
- Can be used with **ALL** paint systems

## MULTIPLE DELIVERY APPLICATIONS



### Pre-Treatment Cut Thru Marker

- For use on small areas
- Quick, easy to use application
- Small, compact design



### Pre-Treatment Cut Thru Wipes

- For use on medium size areas
- Quick Drying
- No preparation necessary



### Pre-Treatment Sponge

- For use on larger areas
- Holds 4oz. of Pre-Treatment solution
- 2-in-1 design, includes sponge and scuff pad

## How it Works

The pre-treatment system creates a chromium free conversion coating which bonds with metal surfaces enhancing adhesion and corrosion resistance.

Applications: Steel, Stainless Steel, Galvanized Steel, Aluminum



Pre-Treatment Refill Pouch



## Canister w/100 Wipe Pouch

5001

Easy to use canister with one refill pouch containing 100 pre treatment wipes. Ideal for body shop use.



## Refill Pouch

5002

Refill pouch used with Pre-Treatment canister containing 100 9"x 9" wipes.



## Single Application Wipe

5003

One large 12"x 13" wipe, ideal for large and multiple areas. Easy to use, tear open foil pouch.



## Cut Thru Marker

5004

Excellent for use on small areas, chips, and character lines. Easy to transport design.



## Pre-Treatment Sponge

5005

Ideal for large areas such as complete car/truck panels. Contains 4oz. of pre-treatment chemical and recommended for areas of up to 40 sq. ft.

## Directions:

- 1 Apply pre-treatment chemical to clean, bare metal surface.
- 2 Apply a double application of pre-treatment to each area, ensuring complete wetting of the product on the metal surface.
- 3 This wet layer should be on the surface for approximately 1 minute to form a conversion coating with the metal substrate.
- 4 Allow pre-treatment to completely dry before priming or top-coating. If desired, the use of warm or forced air can be used to accelerate drying.

## PRODUCT INFORMATION

<b>Part No.</b>	<b>Description</b>	<b>Units/Case</b>
5001	Canister/Lid with 100 9"x 9" wipes	2
5002	Refill Pouch with 100 9"x 9" wipes	4
5003	1- 12"x 13" wipe in pouch	24
5004	Felt marker with 1.5 oz. Pre-Treatment solution	12
5005	Scuff sponge with 4 oz. of Pre-Treatment solution	12



Marker Case - 12 units



Wipe Case - 24 units