

CAUTION!



ALWAYS USE APPROPRIATE EYE PROTECTION (UV ENHANCING GLASSES) WHEN OPERATING LIGHT. Protect eyes during operation. Do not look directly at the light during operation. Exposure to UV light, even for a brief period can damage your eyes.

Operating Instructions

IMPORTANT!

Studies have proven that the use of UV Enhancing Glasses (supplied) allow the user to find and spot leaks easier and faster.




- 1) Put on UV Enhancing Glasses (supplied).
- 2) Turn on lamp by depressing switch on rear of lamp.
- 3) Scan the area with the UV lamp.
- 4) Adjust focus/intensity by turning head on lamp.

A fluorescent glow will appear from leaks. For optimum results do not use lamp in bright sunlight and make sure to wear the UV Enhancing Glasses as they will allow you to more clearly see the fluorescent glow of the dye.

Replacement Parts

1) 98006433 - UV Phazer BLACK lamp





Operating Instructions

