

Assembly instructions

Clip-on [weights](#)

1. Selection of a suitable weight



Before installation, the weight matching the rim shape is selected. The build of the rim is used for differentiation. Before installation to the rim, apply the weight to check its fit.

2. Place the weight on the rim



Place the weight at the correct location of the imbalance. Before you knock on the weight with a hammer, make sure that the clip touches the rim flange. The actual body of the weight should not touch the rim.

3. Knock on the weight



After correctly aligning the weight, it is knocked on with the corresponding installation hammer. Do not use more than two strong hits for installation. Note: Increasing the impact number can damage the weight coating.

4. Check correct fit of the weight



We recommend a second inspection to confirm the weight is attached firmly after installation.