



SeatSaver™ Installation Instructions

BEFORE INSTALLATION, PLEASE READ THIS SECTION CAREFULLY.

Thoroughly inspect each of your SeatSavers before installation to determine if any or all of the following special features apply to your specific seat style. Some of the information presented in this instruction sheet may or may not apply to your specific installation. Please be sure to use the applicable information for your installation.

SPECIAL POINTS TO WATCH FOR & CONSIDER:

- 1 - Contour of seat back and cushions, including separate headrest and/or armrest covers. Some sets **may** have additional headrest covers to accommodate optional-sized headrests.
- 2 - Cutouts for seat adjustment levers and buttons, shoulder harness retaining brackets and stationary seat belt harnesses.
- 3 - Hook & loop attachments on elastic straps sewn onto the underside of the bottom cushion.
- 4 - Hook & loop attachments along the bottom outside edge near the crevice area between the seat back and the bottom cushion.
- 5 - Cloth-type belt with hook & loop attachments. Large cloth loop.
- 6 - Side release buckles with webbing straps.
- 7 - Be sure that no hook & loop attachments are connected to other pieces prior to starting the installation.

INSTALLATION INSTRUCTIONS

If your vehicle is equipped with brackets on the outboard side of the backrest, check the covers to determine if an opening has been provided for them. If not, they must be removed before installation of the SeatSavers. If your covers have a belt loop sewn at the bottom, make sure it slips over the backrest while completing "Step 1".

Step 1: Slip the SeatSaver over the backrest, watching for any or all of the special points mentioned above.

Step 2: Pull the cover down snugly over the entire back until the top and sides fit the contour of the backrest.

Step 3: Lean the backrest forward and pull the bottom of the SeatSaver forward to stretch the elastic over the bottom cushion. Be aware of any special points mentioned above.

Step 4: If so equipped, slip the two elastic straps sewn onto the underside of the bottom cushion cover **through** the crevice between the seat back and bottom cushion...**OR**, if so equipped, insert the flap with the hook & loop attachment **through** the crevice. Mate the elastic straps or the flap with hook & loop strips to the hook & loop on the bottom and/or rear edge of the bottom cushion part of the cover. Return seat back to upright position.

Step 5: If your SeatSavers have the cloth-type belt with hook & loop attachments, slip the belt around and under the bottom cushion and secure the hook & loop together.

Step 6: Make sure any cutouts in the SeatSavers have been aligned properly, and that any hook & loop or side release buckle attachments are securely fastened.

Step 7: With the backrest again tilted forward, gently press the SeatSaver into the crevice between the backrest and bottom cushion. Return seat back to upright position.

CARE & CLEANING INSTRUCTIONS

Wash your SeatSavers in a conventional washing machine, using cold water, a low-sudsing detergent and a gentle cycle setting. Do **NOT** use bleach or fabric softener.

Dry the covers using the "air" or "low heat" setting on a standard tumble dryer. They may also be line dried, weather conditions and temperature permitting. Do **NOT** iron.

Form # 3320906 (5/16)