

# TopCoat Application

**Use LizardSkin TopCoat to add durability, traction, and a glossy finish to your LizardSkin application.**

1. Ensure that LizardSkin CI and/or SC has fully cured prior to application and that no dust or other foreign matter is on the coating. Protect surrounding areas from spray mist. For best results, use when both TopCoat can and surface temperature are between 50°F and 90°F (10°C and 30°C).
2. Shake can at least one minute after rattle is heard and occasionally during use.
3. Spray surface with steady even strokes at a distance of 8 to 10 inches (20 to 25cm). Several light coats give a better finish than one heavy coat.
4. If clogging develops, turn nozzle 1/4 turn or remove and clean spray head slot. Do not stick pin or other objects into can opening. With can and nozzle pointed away from you, reinsert nozzle with a gentle twisting motion.
5. To clear nozzle for future use, turn can upside down and spray for 3 seconds. Completely empty cans may be recycled or disposed of with regular trash. DO NOT incinerate or compact.