

# 19740 Inline Strainer Fitting

## **WARNING**



- Unplug the station before beginning service work. Incorrect use or connections can cause electrical shock.



- Wear safety goggles when working with refrigerants. Refrigerants can cause eye injury.



- Disconnect hoses using extreme caution! Pressurized refrigerant may be present in hoses. Point hoses away from you and anyone nearby.


## Instructions

### Installation

1. Install inline strainer on liquid port of source tank.
2. The low-side adapter will be used for machines without a tank fill hose. Connect source fill hose to fitting.

### Cleaning the Strainer Tip

1. Unscrew fitting and remove strainer tip.
2. Blow debris out of strainer tip with an air hose until clean.
3. Assemble fitting.
4. Install onto tank.



**ROBINAIR**  
AN SPX BRAND

Because of ongoing product improvements, we reserve the right to change design, specifications, and materials without notice.