



# INSTALLATION INSTRUCTIONS

## 1½" PRESSURE GAUGES



### Preliminary Steps

1. Read instructions thoroughly. Please consult a qualified mechanic if you have not had training in the proper installation of instruments.
2. Determine ideal mounting location. Consult your vehicle's repair manual to locate:
  - A) Fuel Pressure Port
  - B) Oil Pressure Port
  - C) Any other Pressure port

**CAUTION:** Some late model vehicles use electronic sensors in their pressure and temperature senders for engine control functions. Before removing the original senders, we recommend that you contact your Auto Dealer to be sure no critical functions will be disrupted. With pressure gauges, it is beneficial to add a T-fitting to install your new gauge and to keep the warning light operational. This allows you to monitor the pressure and still have a warning light to indicate emergency conditions.

### INSTALLATION

1. Locate pressure port.
2. Install T-fitting if needed.
3. Apply teflon sealing tape or compound to insure a leak-free connection.
4. Install gauge into pressure port, being careful not to over tighten.
5. After installation, start engine and check all connections for leaks.



Use Teflon Sealing Tape Or Sealing Compound On Pipe Threads.

