



Part#: 124339, 124369

Product: **Rear Fixed Lower Control Arms**

Application: **Jeep Wrangler JK**

---

**READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.**

---

## INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the front wheels for safety. Raise the rear of the vehicle and support it with jack stands under the frame in front of the lower control arm mounts.
2. If installing the 124369 control arm kit, grease and install the provided bushings and sleeves into the control arm ends. Install the 90 degree grease fittings in the threaded holes at each end and index so the fittings point toward the center of the arm. Use lithium-based grease only.

◆ *Optional: Remove the wheels. This will give better access to the work area.*

3. Support the axle with a hydraulic jack.

◆ *Optional: Disconnect the track bar from the axle. This will aid in realignment of the control arm bolts by allowing the axle to be centered under the vehicle at all times.*

4. With the axle well supported, remove the lower control arm bolts at the axle and frame. Remove both lower control arms from the vehicle. Save hardware.
5. Using the OE hardware, install the control arm with the bend up for maximum ground clearance. The bend is centered on the arm. Leave all hardware loose. It will be tightened with the vehicle at ride height.
6. If removed, re-install the wheels.
7. Lower the vehicle to the ground and bounce the rear to settle the suspension.
8. If disconnected, install the track bar to the axle with the OE hardware and tighten to OE specs: 125 ft-lbs.
9. Tighten the control arm axle and frame bolts to OE specs: 125 ft-lbs.
10. Check all fasteners for proper torque.
11. Check all fasteners after 500 miles.

## PARTS LIST

Part #	Qty	Description
A182	2	Rear Fixed LCA w/ Rubber Bushing
OR		
A189	2	Rear Fixed LCA w/Poly Bushings
3537BK	8	Polyurethane Bushing
61	4	7/8" x 2.620" Sleeve
60107	4	90 deg Grease Fitting