Effective June 2017 Supersedes December 1998

HR and HM

1/4" x various length and SFE in-line fuse holder



Product features

- Bayonet type knob
- Maximum current rating 20 amps; voltage • rating 32 volts AC
- · Holders available as complete assembly consisting of in-line holder with 8" or 14" of #14 insulated wire and installed fuses
- Replacement springs BK/1A1853
- Replacement contacts 9838 for #18 #22 wire, 9841 for #12 - #16 wire

Environmental data:

Temperature Rating (RTI): +140 °C

Agency information:

No agency listing

Part				
Number	Amps	Volts AC	Includes Fuse	Wire
HRJ*	20	32	SFE-20	- 19″ of #14
HRI			SFE-14	
HRH			SFE-9	
HRE			SFE-71/2	
HRG			SFE-6	
HRF			SFE-4	
HMJ**			SFE-20	8″ of #14
HMI			SFE-14	
HMH			SFE-9	
HME			SFE-71/2	
HMG			SFE-6	
HMF			SFE-4	

BUSSMANN

*Also available as in-line fuseholder only with lead wire contacts, HRJ-Less-Fuse

**Also available as in-line fuseholder only with lead wire contacts, HMJ-Less-Fuse.

HUJ-Less-ruse. HDJ-A – For $\frac{1}{4''} \times \frac{1}{4''}$ fuse, no wire or fuse included, accepts #18 - #20 wire. HDJ-B – For $\frac{1}{4''} \times \frac{1}{4''}$ fuse, no wire or fuse included, accepts #12 - #16 wire. HDI-A – For $\frac{1}{4''} \times \frac{1}{4''}$ fuse, no wire or fuse included, accepts #18 - #20 wire. HDI-B – For $\frac{1}{4''} \times \frac{1}{4''}$ fuse, no wire or fuse included, accepts #12 - #16 wire. HAF-A – For $\frac{1}{4}$ × $\frac{5}{8}$ fuse, no wire or fuse included, accepts #18 - #20 wire.

Dimensions: in (mm): All dimensions ±0.015"



