



P/N 91835FLT (painted) & 91835-1FLT (ceramic coated)

CHEVY/GMC HEADERS

99-02 Chevy/GM Pickup/Suburban/Yukon/Escalade & 03-04 GM Pickup

6.0L w/ EGR (2 & 4WD)

C.A.R.B. E.O. D-115-16

Thank you for making FLOWTECH HEADERS your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled FLOWTECH to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your FLOWTECH exhaust system.

WARNING! Breaking in an engine with ceramic-coated headers WILL result in damage to the coating and will VOID all warranties. Ceramic-coated headers require several heat cycles to fully cure before they will withstand extreme heat. FLOWTECH recommends using a cast-iron exhaust manifold or an old header to break in new engines to avoid coating damage.

NOTE: This tuned shorty style header is designed to be a direct replacement for the OEM GM exhaust manifolds and is exempted from the prohibition of Section 27156 of the California Vehicle Code (C.A.R.B. E.O. D-115-16).

BEFORE STARTING

Your vehicle must be raised a minimum of 36 inches. A floor hoist is ideal. If no hoist is available, we strongly urge the use of axle stands as a safety measure.

CAUTION! YOUR CAR SHOULD NOT BE SUPPORTED ON A BUMPER JACK.

We recommend welding all pipe slip joints. If no welding equipment is available at the time of installation, use the furnished clamps to secure the pipes until they can be welded.

CAUTION! To avoid damage to the air bag system, do not rotate a disconnected steering shaft more than 180°.

INSTALLATION PROCEDURE – PLEASE READ CAREFULLY

1. Disconnect the battery.
2. Unbolt the flange nuts where the manifold connects to the exhaust system.
3. Disconnect the spark plug wires and remove the spark plugs to avoid any damage.
4. Remove the through-bolt from the steering shaft. Slip the shaft apart.
5. Disconnect the EGR tube from the right side exhaust manifold.
6. Remove the dipstick tube from the right side of the engine.
7. Unbolt the left and right side exhaust manifolds and remove from the vehicle.
8. Install the left and right header from above, using supplied the gaskets and hardware.
9. Re-install the EGR tube and tighten all the bolts evenly and to the manufacturer's torque specs.
10. Re-install the dipstick tube and reconnect the steering shaft.
11. When finished with the installation, give your vehicle a test drive checking carefully for any new noises. After several days of driving, re-tighten all the bolts.