


IMPORTANT!

PLEASE READ BEFORE INSTALLING YOUR SHAFT!

Make sure the U-Bolts holding the shaft to the pinion yoke are not too tight. Snug is different for each of us and overtightening clamps the bearing, causing drag



which, in turn, causes vibration and heat. **ACTION:** Proper torque is 14-17 foot-pounds for 1-1/16 and 1-1/8 inch diameter caps, and 20 foot-pounds for 1-3/16 inch diameter caps. Since you can't get a torque wrench onto the U-Bolts, an approximation of these torque values is flattening the lock washer and adding about an eighth of a turn of the nut.

If you're looking for quality performance driveline & axles parts, visit our website.