



WATERPROOF L.E.D. LIGHTING INSTALLATION INSTRUCTIONS

SUGGESTED TOOLS

Wire Stripper Drill & 1/8" Bit Pencil Masking Tape Tape Measure 12 volt test light

SURFACE PREPARATION

Before mounting Custom L.E.D. Lighting, clean the mounting surface of dirt or other contaminants.

INSTALLATION

- 1) Position the L.E.D. Light in approximate mounting location, noting electrical wiring direction & routing.
- 2) If drilling a wire hole is necessary, use masking tape and a pencil, mark hole and drill using an 1/8" drill bit.
- 3) If drilling mounting holes are necessary, use masking tapea pencil, mark holes and drill using proper drill bit to match screw being used.
- 4) Secure light to mounting surface.
- 5) Route wire to desired location.
- 6) (-) Negative - Connect black wire to a good chassis ground.
- 7) (+) Positive - Connect black/white wire to a 12V switch source.
- 8) Test lights for correct function*. Installation is complete.

Note: Do not install this product if outside temperature is below 60°F or above 90°F. Do not subject Mini L.E.D. Light to extreme temperatures, water or road contaminants for 24 hours after installation to allow adhesive to fully bond to mounting surface.

TROUBLESHOOTING

If Light does not work on initial installation, switch the (-) Negative wire to (+) Positive source and (+) Positive to (-) Negative source. L.E.D. Lights are polarity specific.

Warning: Installation of accessories should only be undertaken by those with mechanical and electrical knowledge and are familiar with working on vehicles. Always use eye protection (goggles, safety glasses or shield). Park the vehicle in a well lit area, on level ground and apply the parking brake. After installation, check all lights and electronic functions thoroughly. Failure to follow instructions can lead to severe damage and personal injury.