



SPYDER™

SKU# 5085733



SCAN THE QR CODE TO
VIEW THE INSTALL VIDEO

PACKAGE CONTENTS:



• 2X TAIL LIGHT ASSEMBLIES

FITMENT:

• 2016-2019 TOYOTA TACOMA

-  [FACEBOOK.COM/SPYDERAUTO](https://facebook.com/spyderauto)
-  [LINKEDIN.COM/COMPANY/SPYDER-AUTO](https://linkedin.com/company/spyder-auto)
-  [INSTAGRAM.COM/SPYDERAUTO](https://instagram.com/spyderauto)
-  [TWITTER.COM/SPYDERAUTO](https://twitter.com/spyderauto)
-  [TIKTOK.COM/@SPYDERAUTO](https://tiktok.com/@spyderauto)



SCAN THE QR CODE
TO VISIT OUR WEBSITE


WARNING: BY READING THIS DOCUMENT, YOU AGREE IT IS ONLY TO BE USED AS AN EDUCATIONAL GUIDE. SPYDER AUTO NOR ITS DEALERS MAKE GUARANTEES ON ANY FINISHED RESULTS, NOR ARE THEY TO BE HELD RESPONSIBLE FOR ANY DAMAGE, MISUSE, OR PERSONAL INJURIES. IF YOU ARE UNABLE TO CLEARLY UNDERSTAND AND ADAPT THE INFORMATION BELOW, PROFESSIONAL INSTALLATION IS RECOMMENDED. FOR ANY ISSUES OR QUESTIONS ABOUT YOUR SPYDER PRODUCT, REACH OUT TO OUR TECH SUPPORT TEAM TECHSUPPORT@SPYDERAUTO.COM. IT IS THE INSTALLER'S RESPONSIBILITY TO CONFIRM COMPLIANCE WITH STATE AND LOCAL LAWS. THIS PRODUCT CAN EXPOSE YOU TO CHEMICALS INCLUDING CHROMIUM (HEXAVALENT COMPOUNDS), WHICH ARE KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER AND BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM. FOR MORE INFORMATION GO TO WWW.P65WARNING.CA.GOV

TOOLS REQUIRED:

- RATCHET
- 10MM SOCKET



STEP 1:
DISCONNECT THE NEGATIVE BATTERY TERMINAL




STEP 2:
REMOVE (2) 10MM BOLTS



STEP 3:
UNSEAT TAIL LIGHT



STEP 4:
REMOVE (3) BULB SOCKETS




STEP 5:
REMOVE (3) BULBS FROM THE SOCKETS



STEP 6:

INSTALL TOP SOCKET INSERTS. (ALIGN YELLOW WIRE FROM SOCKET TO RED WIRE OF SOCKET INSERT) REINSTALL SOCKET



STEP 7:

INSTALL MIDDLE SOCKET INSERT. (ALIGN RED WIRE FROM SOCKET TO RED WIRE OF SOCKET INSERT) REINSTALL SOCKET



STEP 8:

INSTALL BOTTOM SOCKET INSERT. (ALIGN BLUE WIRE FROM SOCKET TO RED WIRE OF SOCKET INSERT) REINSTALL SOCKET



STEP 9:

SEAT SPYDER TAIL LIGHT



STEP 10:
REINSTALL (2) 10MM BOLTS



STEP 11:
RECONNECT THE BATTERY AND TEST THE FUNCTIONS TO ENSURE THEY FUNCTION PROPERLY