



Running Board

Part No. R0005MK/R0002RB




Fits: 2010 - 2013
2014 - Current

Toyota 4Runner SR5 & Limited
Toyota 4Runner Limited



60-180 min



Cutting Not Required




Drilling Not Required



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.




READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.

PARTS LIST:


Qty	Part Description	Qty	Part Description
1	Driver/Left Running Board	12	8mm x 22mm OD x 2mm Flat Washers
1	Passenger/Right Running Board	12	6mm x 20mm "T" bolts
2	Front Mounting Brackets	12	6mm Lock Washers
4	Center & Rear Mounting Brackets	12	6mm x 22mm OD x 2mm Flat Washers
12	8-1.25mm x 30mm Hex Bolts	12	6mm Hex Nuts
12	8mm Lock Washers		



Install Note: 200lbs is the maximum rated load for the viewpoint running boards.

INSTALLATION PROCEDURE

1. Starting on the passenger side of the vehicle, remove the existing (2) factory bolts located by the front tire opening securing the factory rocker panel bracket to the vehicle, (**Figure 1**). Select (1) Front Mounting Bracket. Hold the Front Bracket over the rocker panel bracket and line up the (2) mounting holes. Secure the brackets to the vehicle using the included longer (2) 8mm x 30mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, (**Figure 2**). Do not tighten hardware at this time.



(Fig 1) Passenger side front mount pictured

Remove factory hex bolts

Install the Mounting Brackets one at a time over the factory rocker panel brackets





Fig 2

(2) 8mm x 30mm Hex Bolts
(2) 8mm Flat Washers
(2) 8mm Lock Washers

2. The center and rear brackets are identical. Select (1) Center/Rear Bracket and repeat the procedure as described in **Step 1** to install it in the center mounting location, (**Figure 3**). **NOTE:** Install (1) mounting bracket at a time. Do not tighten hardware at this time.





(Fig 3) Passenger side rear bracket location pictured





(Fig 4) Insert T-Bolts into channels on bottom of Running Board

3. Repeat **Step 2** for rear Mounting Bracket installation.
4. Carefully unwrap the Running Board and select passenger side Board. Select (6) 6mm T-Bolts. Insert (3) T-Bolts into each channel on the bottom of the Running Board, (**Figure 4**). Slide the T-Bolts forward or back to line up with the (3) previously installed Mounting Brackets, (**Figure 5**). Hold the Running Board up to the vehicle at a slight angle and gently push it into position against the rocker panel, (**Figure 6**). Line up the T-Bolts with the slots in the Brackets.



Tilt the Running Board up and gently push back into position against rocker panel. Line up T-Bolts with Brackets

5. Attach the Running Board to the Mounting Brackets with the included (6) 6mm Flat Washers, (6) 6mm Lock Washers and (6) 6mm Hex Nuts, (**Figures 7 & 8**). Do not tighten at this time.



6. Level and adjust the Sidebar as desired and tighten all hardware. Repeat **Steps 1 – 5** for the driver side Running Board installation.



PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's

1. Hardware's are not of correct size.

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. Products are thumping / rattling after installation.

Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.

Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.

5. Missing / Excess Hardware.

Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.